

Debittek Cash Register Debit Card Terminal For Sharp 3310 Enhanced Registers Installation and Operation Manual

Table of Contents

[Operating Instructions](#)

[No Card Message](#)

[Card Balance Too Low Message](#)

[Repaying an IOU](#)

[Refunds](#)

[Correcting Entry Errors](#)

[Incorrect IOU](#)

[Incorrect Repay](#)

[EJECT](#)

[Turning Off the Alarm](#)

[Marrying Cards](#)

[Interpreting the Debittek Report](#)

[Sales by Line Item](#)

[Period Totals](#)

[Programming the Sharp 3310 Enhanced](#)

[Hardware](#)

[Required Keys for the Sharp 3310](#)

[Service Mode Programming](#)

[Job #902](#)

[Job #913](#)

[Job #914](#)

[PGM2 Mode Programming](#)

Job #395
Job #370
Job #371
Job #372, 373, and 374
Job #234
Job #260
Job #262

Z1/X2/Z2 Mode Programming

The [CA/AT] Key

Operating Instructions

The operation of the Sharp 3310 with a Debittek Cash Register Debit Card Terminal (DCT) is very similar to a non-card system. In normal operation, the only difference is which tender key is pressed to complete the transaction; use [DEBIT] for card and [CASH] for cash. Special procedures for debit card operation are covered below.

No Card

Pressing [DEBIT] with no card in the DCT causes the following error message:

COLLECT \$x.xx

An alarm will sound. Ask the customer to insert their card, and the Debittek DCT will deduct the proper amount from the card. If the transaction was intended to be a cash sale and [DEBIT] was pressed in error, refund the previous card sale and re-enter the transaction as a cash sale. See the "Refunds" section in this manual for details on refunding a debit transaction.

Card Balance Too Low

If the amount of the transaction is greater than the balance on the card, the card balance will be reduced to \$0.00, and the card will be ejected. The amount remaining will be displayed in the following message along with an alarm:

COLLECT \$x.xx

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/sharp/Debitek Card Terminal for Sharp 3310 Open>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)