| | | 91 - | , |
|---|---|----------------------------------|----------------------------------|
| 6. Service Mode (SRV) Operation | | Fig. 6-1 | |
| To go into SRV mode, the service key (LKGIM7113RCZZ) is required for service mode operation. | ي. بيني | Initiai Preset Aft (ER2385) | er Master Reset (ER2395) |
| 6-1. Reset Operation | • | $\sim\sim\sim\sim$ | |
| At SRV mode (SRV1), the following 2 types of reset operations are provided. | | 00-00-00 | 00-00-00 |
| (1) Master Reset When the Master Reset is excuted, the data stored in all the memories will be initialized such as preset memories. And all the totalizers/counters/date and time are cleared to zeroes. | a sana Ang ang ang ang ang ang ang ang ang ang a | 900# | 900# |
| [Key Operation] ① Turn the mode switch to SRV2 mode. ② Holding down the numeric 9 key, then turn the mode switch to | | 901 0002 902 0015 903 0510 | 901 0002 902 0015 903 0810 |
| ³ (For ER2385) (For ER2395) | | 903 0510 | |
| (FOT ER2395) (FOT ER2395) | 19.20 | 905 1331 | 904 3070 |
| Enter 90 and press CAAT key. Enter 91 and press CAAT key. | Service | 906 3505 | 906 3555 |
| 9 1 - CAVAT | preset | 907 3577 | 907 3577 |
| (Upon pressing CAAT key, the master Reset is finalized. | . | 908 1037 | 908 5127 |
| Note: To verify the contents of the memories after Master Reset or | | 909 7777 | 909 7777 |
| Service Preset programming. A print message shown in Fig. | * 11 × 1 | 910 3173 | 910 7173 |
| 6-1 is given by doing following key operation. | | 911 7733 | 911 7733 |
| 900- @/FOR - CA/AT | | | |
| | Z1, Z2 counters | Z 0000 1 | Z 0000 1 |
| (3) Program Reset By turning the mode switch from SRV2 to SRV1 mode, the register | | Z 0000 2 | |
| returns to initial status even while in a locked status or any registrations. | GT1 | - 1 | |
| However, all the data before the reset are kept maintained except for resetting date and time memories. | totalizer | 000000 | 000000 |
| (2) A second se second second sec | | - 2 fi | 2 |
| Note: Job #901-D (Tabulation preset) varies by each country though, after Master Reset it will always be set at 2 (0.00). | GT2 | | 000000 |
| Therefore, you may be required to re-program the tabulation suitable for your country. | totalizer | 0000.00 | 0000.00 |
| | | - 3 | 3 |
| | GT3 | -000000 | -000000 |
| InkRoller | totalizer | 0000.00 | 0000.00 |
| PIN NROLR6638RCZZ | | | |
| \$166.45 | Time | [12-00 | 12-00 |
| | | 000-0001 | 000-0001A |
| | | h | J LANTA |
| | | Register No. | |
| | | Consecutive Num | ber |
| | | | Cashier Code |
| | | | · · · · · |
| | | | |
| | · • | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store: https://the-checkout-tech.com/manuals/sharp/ER-2385 and ER-2395 SRV Mode program

And our free Online Keysheet maker: https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM