



## Digital Fieldbus Transmitter

# PR 1720/00, -/01, -/10, -/11

## Operating Manual



Operating Manual  
for PR 1720

9499 050 72003  
Release 2.50

Edition 3

29.06.2004

## Contents

<b>1 DESCRIPTION .....</b>	<b>7</b>
<b>1.1 INTERFACES .....</b>	<b>8</b>
1.1.1 <i>Serial interfaces</i> .....	8
1.1.2 <i>Fieldbus interface</i> .....	9
1.1.3 <i>Analog output</i> .....	9
1.1.4 <i>Digital interfaces</i> .....	9
<b>1.2 LIMITS .....</b>	<b>10</b>
<b>1.3 CONTROL SIGNALS .....</b>	<b>10</b>
<b>1.4 REMOTE DISPLAY.....</b>	<b>10</b>
<b>2 SAFETY HINTS, POWER CONNECTION .....</b>	<b>11</b>
<b>2.1 INITIAL INSPECTION .....</b>	<b>11</b>
<b>2.2 MOUNTING POSITION .....</b>	<b>11</b>
2.2.1 <i>Housing in stainless steel (Version PR 1720/10 and -/11)</i> .....	12
<b>2.3 BEFORE COMMISSIONING .....</b>	<b>12</b>
<b>2.4 OPENING THE INSTRUMENT .....</b>	<b>12</b>
<b>2.5 SUPPLY VOLTAGES/MAINS CONNECTION .....</b>	<b>13</b>
2.5.1 <i>24 VAC version PR 1720/01 and -/11</i> .....	13
<b>2.6 MAINTENANCE .....</b>	<b>14</b>
2.6.1 <i>Fuse</i> .....	14
2.6.2 <i>Soldering</i> .....	14
<b>2.7 REPAIR .....</b>	<b>15</b>
2.7.1 <i>For special attention</i> .....	15
2.7.2 <i>Failure and excessive stress</i> .....	15
<b>2.8 DISPOSAL .....</b>	<b>15</b>
<b>3 INSTALLATION .....</b>	<b>16</b>
<b>3.1 CONNECTIONS .....</b>	<b>16</b>
<b>3.2 CONNECTION OF 2 TO 8 LOAD CELLS VIA PR 6130 CABLE JUNCTION BOX .....</b>	<b>18</b>
3.2.1 <i>Direct connection of 1 load cell</i> .....	18
<b>3.3 CONNECTION OF 2 TO 4 LOAD CELLS WITH PR 1722 CONNECTION SUB-UNIT .....</b>	<b>19</b>
<b>3.4 DIGITAL OUTPUTS .....</b>	<b>20</b>
<b>3.5 DIGITAL INPUTS .....</b>	<b>20</b>
<b>3.6 ANALOG OUTPUT .....</b>	<b>21</b>
<b>3.7 OPERATOR/SERVICE INTERFACE RS232 .....</b>	<b>22</b>
<b>3.8 SERIAL (COMMUNICATION) INTERFACES .....</b>	<b>23</b>
3.8.1 <i>RS 232</i> .....	24
3.8.2 <i>Current loop</i> .....	25
3.8.3 <i>RS 422/485</i> .....	26
3.8.4 <i>RS422/485 BUS</i> .....	27
3.8.5 <i>RS 422/485 BUS 2-wire</i> .....	28
3.8.6 <i>Solder links on the interface modules</i> .....	29
<b>3.9 PR 1721 FIELDBUS INTERFACE .....</b>	<b>30</b>
3.9.1 <i>PR1721/11 Profibus-DP (option)</i> .....	31
3.9.2 <i>PR1721/12 Interbus-S (Option)</i> .....	32
3.9.3 <i>PR1721/14 DeviceNet Interface</i> .....	33
<b>4 SURVEY/FUNCTION .....</b>	<b>35</b>
<b>4.1 FUNCTION BLOCKS .....</b>	<b>35</b>

4.1.1	<i>Galvanic isolation</i> .....	35
4.2	DATA BACK-UP/MAINS FAILURE .....	36
4.2.1	<i>Calibration data</i> .....	36
4.2.2	<i>Configuration data</i> .....	36
4.3	SURVEY OF PARAMETERS CALIBRATION/CONFIGURATION.....	37
4.3.1	<i>Limit, fixed tare, fixed analog output value</i> .....	37
4.4	COMMISSIONING .....	38
4.4.1	<i>Terminal configuration</i> .....	38
4.4.2	<i>Boot messages</i> .....	39
4.4.3	<i>Start-up screen, Operating level</i> .....	40
4.4.3.1	Weight display .....	40
4.4.3.2	Status display .....	40
4.4.3.3	Key functions .....	41
4.4.3.4	Menu control in the masks.....	41
4.4.4	<i>Entry of parameters for limits and fixed tare value</i> .....	42
4.4.5	<i>SPM marker, setting/resetting via the terminal</i> .....	44
5	CALIBRATION .....	45
5.1	ENTRY PROCEDURE – CALIBRATION .....	45
5.2	CALIBRATION MENU .....	46
5.3	MEASUREMENT PARAMETER FILTERS .....	48
5.4	CALIBRATING THE INDICATOR .....	49
5.4.1	<i>Calibration by means of weights</i> .....	50
5.4.1.1	Hysteresis correction.....	50
5.4.1.2	Step-by-step calibration.....	51
5.4.2	<i>Adjustment with load cell data</i> .....	52
5.4.2.1	Gravity: increased accuracy due to gravity correction.....	52
5.4.3	<i>Adjustment via SPAN, entry of mV/V data</i> .....	53
5.4.3.1	SPAN calculation in mV/V.....	53
5.4.4	<i>End of calibration</i> .....	54
5.5	CHANGING THE CALIBRATION SUBSEQUENTLY .....	55
5.6	ERROR MESSAGES .....	56
5.6.1	<i>Error messages on the weight display</i> .....	56
5.6.2	<i>Error messages during calibration menu selection</i> .....	56
5.6.3	<i>Error messages during the calibration menu</i> .....	56
6	CONFIGURATION .....	57
6.1	CONFIGURING THE ANALOG OUTPUT .....	58
6.2	CONDITIONS FOR LIMIT VALUES, DIGITAL INPUTS AND OUTPUTS.....	60
6.2.1	<i>Configuring digital inputs and outputs</i> .....	61
6.2.1.1	Configuring outputs .....	61
6.2.1.2	Configuring inputs .....	62
6.2.2	<i>Configuring limit values</i> .....	63
6.3	TERMINAL KEY CONFIGURATION .....	65
6.4	ACCESS CODES .....	66
6.5	CONFIGURING OPERATING INTERFACE FOR REMOTE DISPLAY OPERATION.....	67
6.6	CONFIGURING FIELD BUS INTERFACE AND PROTOCOL.....	68
6.6.1	<i>Interbus S selection</i> .....	68
6.6.2	<i>Profibus DP selection</i> .....	68
6.6.3	<i>DeviceNet</i> .....	69
6.7	SERIAL INTERFACE (SUPERVISORY SYSTEM) .....	70
6.7.1	<i>Printer</i> .....	71
6.7.2	<i>Remote display at serial interface</i> .....	72
6.8	DISPLAY .....	74
6.9	SAVE DATA, CREATE/RELOAD BACK-UP FILE .....	75

6.9.1	<i>Save data, create back-up file.....</i>	75
6.9.2	<i>Load data into PR1720.....</i>	76
6.9.3	<i>Print calibration/configuration parameters.....</i>	76
6.9.3.1	<i>Configuring the hyperterminal .....</i>	79
6.10	<b>LEAVING CONFIGURATION AND SAVING THE CONFIGURATION PARAMETERS .....</b>	80
<b>7</b>	<b>CALIBRATION PARAMETERS.....</b>	<b>81</b>
7.1	<b>ANALOG FILTER.....</b>	<b>81</b>
7.2	<b>TEST MODE .....</b>	<b>81</b>
7.3	<b>CALIBRATED AT .....</b>	<b>81</b>
7.4	<b>DIGITAL FILTER.....</b>	<b>81</b>
7.5	<b>DIMENSION .....</b>	<b>82</b>
7.6	<b>DONT PRINT BELOW .....</b>	<b>82</b>
7.7	<b>OPERATION IN W AND M .....</b>	<b>82</b>
7.8	<b>MEASURING TIME .....</b>	<b>82</b>
7.9	<b>ZEROSET RANGE.....</b>	<b>83</b>
7.10	<b>AUTOMATIC ZERO TRACKING .....</b>	<b>83</b>
7.11	<b>ZEROTRACK RANGE.....</b>	<b>84</b>
7.12	<b>ZERO TRACK STEP .....</b>	<b>84</b>
7.13	<b>ZEROTRACK REPEAT TIME.....</b>	<b>84</b>
7.14	<b>RESOLUTION.....</b>	<b>84</b>
7.15	<b>FULLSCAL .....</b>	<b>85</b>
7.16	<b>STEPWIDTH.....</b>	<b>85</b>
7.17	<b>STANDSTILL DETECTION .....</b>	<b>85</b>
7.18	<b>STANDSTILL RANGE .....</b>	<b>85</b>
7.19	<b>STANDSTILL TIME/NUMBER OF STANDSTILL SAMPLES.....</b>	<b>86</b>
7.20	<b>CANCEL TARE COMMAND .....</b>	<b>86</b>
7.21	<b>OVERLOAD .....</b>	<b>86</b>
<b>8</b>	<b>SERIAL COMMUNICATION .....</b>	<b>87</b>
8.1	<b>COMMUNICATION PROTOCOLS .....</b>	<b>87</b>
8.1.1	<i>JBUS protocol/MODBUS protocol.....</i>	87
8.1.2	<i>DUST protocol.....</i>	88
8.1.3	<i>EW protocol.....</i>	89
8.2	<b>TELEGRAMS FOR EW AND DUST PROTOCOL.....</b>	<b>90</b>
8.2.1	<i>Data formats.....</i>	91
8.2.2	<i>Example.....</i>	93
8.2.3	<i>Error codes.....</i>	94
8.3	<b>COMMUNICATION WITH THE JBUS PROTOCOL .....</b>	<b>95</b>
8.3.1	<i>Function 1 or 2: read n bits.....</i>	95
8.3.2	<i>Function 3 or 4: read n successive words.....</i>	96
8.3.3	<i>Function 5: write a bit.....</i>	97
8.3.4	<i>Function 6: write word .....</i>	97
8.3.5	<i>Function 8: Diagnosis.....</i>	98
8.3.6	<i>Function 15: write n successive bits.....</i>	98
8.3.7	<i>Function 16: write n successive words.....</i>	99
8.3.8	<i>J-BUS error messages.....</i>	99
8.3.9	<i>Example program for generating the CRC bytes .....</i>	100
<b>9</b>	<b>SPM ADDRESSES.....</b>	<b>101</b>
9.1	<b>STATUS BITS FOR READING (READ ONLY) .....</b>	<b>101</b>
9.2	<b>STATUS BITS FOR READ/WRITE .....</b>	<b>102</b>
9.3	<b>STATUS BITS STATE-TRIGGERED (STATIC, READ/WRITE) .....</b>	<b>102</b>

9.4	STATUS BITS EDGE-TRIGGERED (READ – SET) .....	102
9.5	BYTES FOR CALIBRATION INFORMATION.....	103
9.5.1	<i>SPM addresses for statuses in the analog part/load cell circuitry.</i> .....	103
9.6	NUMERIC WEIGHT VALUES, 32-BIT TWO'S COMPLEMENT .....	104
9.6.1	<i>Printed weight values.....</i>	104
9.6.2	<i>Limit values and fixed values.....</i>	104
10	FIELDBUSES .....	105
10.1	INTERBUS-S, PROFIBUS-DP AND DEVICENET .....	105
10.1.1	<i>Technical data fieldbusses.....</i>	105
10.1.2	<i>Interface function Profibus-DP, DeviceNet.....</i>	106
10.1.3	<i>Interface function Interbus-S.....</i>	106
10.1.4	<i>Process data .....</i>	106
10.1.4.1	<i>Data description .....</i>	107
10.1.4.2	<i>Output area.....</i>	107
10.1.4.3	<i>Input area .....</i>	107
11	TECHNICAL DATA .....	111
11.1	CHARACTERISTICS, SPECIFICATIONS.....	111
11.2	GENERAL DATA .....	111
11.3	ACCURACY AND STABILITY .....	111
11.3.1	<i>A/D Conversion.....</i>	111
11.3.2	<i>Sensitivity .....</i>	111
11.4	LOAD CELLS .....	112
11.5	LOAD CELL CONNECTION .....	112
11.6	ANALOG OUTPUT .....	112
11.7	DIGITAL INPUTS .....	112
11.8	DIGITAL OUTPUTS.....	112
11.9	DISPLAY .....	112
11.10	CONFIGURATION/CALIBRATION .....	113
11.11	SERIAL INTERFACE.....	113
11.11.1	<i>Operating interface/service interface.....</i>	113
11.11.2	<i>Communication interface.....</i>	113
11.12	PROTOCOLS, FIELD BUSSES.....	113
11.13	POWER SUPPLY.....	113
11.14	ENVIRONMENTAL CONDITIONS.....	113
11.15	ELECTROMAGNETIC COMPATIBILITY.....	114
11.16	RF INTERFERENCE SUPPRESSION .....	114
11.17	CE-CONFORMITY .....	114
11.18	CONNECTION .....	114
11.19	TYPE OF CONSTRUCTION.....	114
11.20	DIMENSIONS, WEIGHT .....	114
11.21	ACCESSORIES.....	114
12	ANNEX .....	115
12.1	GSD FILE FOR PR1721 PROFIBUS DP.....	115
12.2	EDS-FILE FOR PR1721 DEVICENET .....	116
12.3	PTB CERTIFICATE .....	117
12.4	INDEX.....	118

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sartorius/PR-1720 operating manual.html](https://the-checkout-tech.com/manuals/sartorius/PR-1720%20operating%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)