NCR RealPOS 70 (7402)

Release 1.4

User Guide



B005-0000-1463
Issue N

Table of Contents

Chapter 1: **Product Overview**

Introduction 1-1
Optional Configurations 1-2
Model and Serial Numbers 1-3
Terminal Dimensions and Weights 1-5
Hinged LCD 1-5
Integrated Hardware 1-6
Operating Systems 1-7
Key Service Advantages 1-8
Removable Motherboard Sled 1-8
Removable Power Supply 1-8
Removable Hard Disk 1-8
Hardware Module Descriptions 1-9
Motherboard 1-9
Processor/Chip Set 1-9
System Memory 1-9
852GME Graphics & Memory Controller Hub 1-10
North Bridge Features 1-10
South Bridge Features 1-11
Video Memory 1-12
BIOS Memory 1-12
Video 1-12
USB Port Functionality 1-14
Ethernet LAN 1-15
Integrated Audio 1-15
Fan Connectors 1-16

Cash Drawer Support 1-17
MSR 1-17
Retail Daughter Card 1-18
PCI Boards 1-18
PCI Riser Board 1-18
PCMCIA Adapter Board 1-18
Dual RS-232 Adapter 1-18
Storage Media 1-19
HARD DISK DRIVE 1-19
Compact Flash 1-19
Operator Display 1-20
LCD Panel 1-20
LVDS 1-20
Inverter 1-21
Touch Screen 1-21
Adjusting the Display Angle 1-22
Integrated Customer Display 1-23
2 x 20 VFD 1-23
All Points Addressable Display 1-23
Motion Sensor 1-24
Power Indicator 1-24
Speakers 1-24
Biometrics Module 1-25
Power Management 1-26
G3 Mechanical Off 1-26
G2/S5 Soft Off 1-26
G1 Sleeping 1-27
G0 Working 1-27
Wake on LAN 1-28

Compatibility 1-29
LAN Communications 1-29
Application Programmability 1-29
Operating System Information 1-29
System Configuration Diagram 1-30

Chapter 2: **Installing the Terminal**

Introduction 2-1
Installation Summary 2-1
Installation Restrictions 2-2
Peripheral Cable Routing 2-3
Installing Peripherals 2-4
Accessing the Cable Connectors 2-5
Cable Connector Identification 2-6
PS/2 Keyboard/Mouse Cable Connections 2-7
Mouse Installation Restriction 2-7
Opening the Display Cabinet 2-8
12.1″ and 15″ Models 2-9
17″ Models 2-10
Powering Up the Terminal 2-11
Terminal On/Off Switch 2-11
Calibrating the Touch Screen 2-13
Out-of-Box Failures 2-14

Chapter 3: **Touch Screen Calibration – Windows *(MT 7.12)***

General Guidelines 3-1
Considerations When Replacing or Re-Imaging the Hard Drive 3-2
Installing the Touch Software 3-2

Hiding the Cursor 3-4
Other Serial Devices Do Not Function 3-7
Touch Calibration Procedures 3-12
Calibration Flow Chart 3-13
3-Point Calibration 3-14
Linearization 3-18
Other Controls 3-23
Main Tab 3-23
Controller ID 3-23
Controller Type 3-23
Firmware Version 3-23
Touch Settings Tab 3-24
Touch Modes 3-25
Right-Click Tool 3-26
Touch Sound 3-26
Double-Click Speed 3-26
Double-Click Area 3-27
Edge Adjustment Tab 3-28
Tools Tab 3-30
Component Versions 3-31
Draw Test 3-32
Restore Factory Settings 3-33
Reset Controller 3-33
Advanced Touch Screen Options 3-33

Chapter 4: **Touch Screen Calibration – Windows *(MT 5.64, SR4)***

General Guidelines 4-1
Considerations When Replacing or Re-Imaging the Hard Drive 4-1

Touch Calibration Procedures....4-2
Installing the Touch Driver....4-2
Calibration Flow Chart....4-8
2-Point Calibration Procedure....4-9
Cursor Stabilization Procedure....4-13
25-Point Linearization Procedure....4-16
Restore Defaults Procedure....4-20
Changing From 4-Point to 2-Point Calibration....4-22
Touch Performance....4-25

Chapter 5: **Touch Screen Calibration – Windows *(MT 5.64, SR6)***

General Guidelines....5-1
Considerations When Replacing or Re-Imaging the Hard Drive....5-1
Installing the Touch Driver....5-2
Touch Calibration Procedures....5-7
Calibration Flow Chart....5-8
2-Point Calibration Procedure....5-9
Cursor Stabilization Procedure....5-12
25-Point Linearization Procedure....5-15
Restore Defaults Procedure....5-19
Touch Performance....5-21

Chapter 6: **Touch Screen Calibration – DOS**

Calibration Flow Chart....6-1
2-Point Calibration....6-3
Noise Check....6-3

Chapter 7: **Installing a Secondary (Dual) Display**

Configuring the Graphics Controller 7-1
Single Display Mode Setup 7-3
Clone Dual Display Mode Setup (DVI and VGA) 7-4
Extended Desktop Dual Display Mode Setup (DVI and VGA) 7-5
Extended Desktop Dual Display Mode Setup (DVI and DVI) 7-6
Extended Desktop Dual Display Mode Setup (VGA and VGA) 7-7
Intel 82852/82855 GM/GME Graphics Controller Hot Keys 7-8

Chapter 8: **Installing Peripheral Options**

Printers 8-1
NCR 7167 Printer 8-1
NCR 7197 Printer 8-2
Installing the Transaction Printer 8-3
Remote Displays 8-5
5964 12.1-Inch Touch Screen 8-5
Features 8-6
Installing an NCR 5964 12.1-inch Touch LCD 8-8
5964 15-Inch Touch Screen 8-11
Installing an NCR 5964 15-inch Touch LCD 8-12
5966 15-Inch Touch Screen 8-15
Installing an NCR 5966 Monitor 8-16
5942 12.1-INCH Color LCD 8-19
NCR 5942 12.1-Inch LCD Monitor Cable Connections 8-20
NCR 5942 15-Inch LCD Monitor Cable Connections 8-21
NCR 5954 15-Inch DynaKey 8-22

Installing an NCR 5954 USB DynaKey 8-23
7452-K419 15-Inch Color CRT 8-25
NCR 5932 Keyboards 8-26
109-Key USB Keyboard 8-26
Features 8-27
115-Key PS/2 Big Ticket Keyboard 8-29
68-Key PS/2 POS Keyboard 8-29
Features 8-30
Remote Customer Displays 8-33
NCR 5972 2x20 Customer Display 8-33
Tall Post Models 8-33
Desktop Models 8-34
Features 8-34
NCR 5973 2x20 International VFD Customer Display 8-35
Features 8-35
Installing an NCR 5972 Remote Customer Display 8-36
Installing a Cash Drawer 8-39
Installing a Second Cash Drawer 8-40

Chapter 9: **Installing the Terminal in an Integrated Configuration**

Introduction 9-1
Exploded Views 9-2
Kit Contents 9-5
Installation Procedures 9-7
Installing the Keyboard 9-8
Installing the Customer Display 9-10
Installing the Transaction Printer 9-13
Installing the 7402 9-15

Chapter 10: **2x20 Customer Display Interface**

Introduction 10-1
General Specifications 10-1
Serial Communication Interface 10-1
Command Codes 10-2
User Defined Character Definition (08h, CODE, Byte1…Byte5) 10-2
Character Table Select (09h, TABLE CODE) 10-3
Clear Display (12h) 10-3
Luminance Control (11h, LUMINANCE) 10-3
Cursor Position (10h, POSITION) 10-4
Reset (13h) 10-4
Character Tables and Codes 10-4
CP437 10-5
CP858 10-6
CP866 10-7
CP932 10-8

Chapter 11: **APA Customer Display Interface**

Introduction 11-1
General Specifications 11-1
Serial Communication Interface 11-1
Architecture 11-2
Display Data RAM 11-2
Display Page Map 11-3
Monochrome Display Mode 11-4
Grayscale Display Mode 11-5
Display Control Bits 11-6
Command Codes (00h - 0Fh) 11-7

Reset (00h) 11-7
Set Luminance (01h, LUMINANCE) 11-7
Set Y Address Register (02h, YAR) 11-7
Set X Address Register (03h, XAR) 11-8
Set Display Control Bits (04h, DCB) 11-8
Write Data Byte (05H, DATA) 11-8
Write Data Page (06h, BYTE1, BUTE2,... BYTE1024) 11-8
Write Data w/Shift (07h, DIRECTION, ROW, BYTE1, BYTE2,... BYTE32) 11-9
Data Write Mode (08h, MODE) 11-10
Character Write Mode (09h, MODE) 11-10
Invert Screen (0Ah) 11-11
Reserved (0Bh - 0Fh) 11-11
Character Codes (10h - FFh) 11-11
5X7 Character Table 11-12
10x14 Character Table 11-13
Command Execution Times 11-14

Chapter 12: **Cash Drawer Interface**

Introduction 12-1
Logic Description 12-1
Component Architecture 12-4
Code Changes 12-4
Hardware/Firmware Interfaces 12-6
Dependencies/Assumptions/Constraints 12-10
Hardware Dependencies 12-10
Software Dependencies 12-10
Sample Code 12-10
CPP Source File: DarlingtonCDSample.cpp 12-10

Header file: DarlingtonCDSample.h 12-26

Chapter 13: **Wedge to USB MSR Software Migration**

Overview 13-1
Software Requirements 13-2
Potential Operational Differences 13-4
Deployment Considerations 13-5
Local Update 13-5
Remote Deployment 13-5

Chapter 14: **Maintenance**

Cabinet and Touch Screen Cleaning Procedures 14-1
Cleaners/Solvents to Use 14-1
Cleaners/Solvents to NOT Use 14-2
Cooling Vent Cleaning 14-3
MSR Cleaning Procedures 14-4

Chapter 15: **Operating System Recovery**

Introduction 15-1
Prerequisites 15-1
OS Recovery Procedures 15-1

Chapter 16: **BIOS Updating Procedures**

Introduction 16-1
Prerequisites 16-1
Creating the Bootable Media 16-2
Creating a Bootable CD 16-2
Creating a Bootable USB Memory Drive 16-2
BIOS Updating Procedures 16-3

Appendix A: **Cables**

Printer Cables A-1
Scanner Cables A-3
7872 or 7875 Scanner/Scale (RS-232) A-3
7892 Scanner (Powered RS-232) A-3
7882 Scanner (Powered RS-232) A-3
7837 Scanner (Powered RS-232) A-4
7837 Scanner (RS-232, External Power) A-4
Display Cables A-5
VGA Display, Mono A-5
VGA Display, Color A-5
CRT AC Power Extension A-5
5972 VFD Customer Display (Powered RS-232) A-6
DVI to DVI A-6
PS/2 - RS-232 & Power A-6
LCD Power Cable A-7
Cash Drawer Cables A-8
Dual Cash Drawer, Y-Cable A-8
Cash Drawer, Extension Cable A-8
Communications Cable A-8
Ethernet, 10/100BaseT A-8
Keyboard Cables A-9
PS/2 Keyboard Extension A-9
Signature Capture/Electronic Payment Terminal Cable A-9
5945/5992 EPT (RS-232 w/Power) A-9
Power Cables (AC) A-10

Appendix B: **Feature Kits**

Appendix C: **Memory Map**

DOS Considerations C-2

Appendix D: **IRQ Settings**

Interrupts D-1

Default Settings D-1

Optional Settings D-2

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/ncr/7402 RealPOS 70 user manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM