NCR 7156 Thermal Receipt and Impact Slip (RS232)

Owner's Guide

BD20-1436-A
Issue B
September 1997

Contents

Chapter 1: About the 7156 Printer 1

Features and Options ... 2
- Receipt Station ... 2
- Slip Station ... 2
- Both Stations ... 2
- General Features ... 3
- Options ... 3

Thermal Printhead ... 3
Impact Printhead ... 3
Ordering Paper and Supplies ... 4
- Ordering Thermal Receipt Paper ... 4
- Ordering Forms ... 4
- Ordering Ribbon Cassettes ... 5
- Ordering Other Supplies ... 5
- Ordering Documentation ... 5

Cleaning the Printer ... 6
- Cleaning the Cabinet ... 6
- Cleaning the Thermal Printhead ... 6

Chapter 2: Setting Up and Using the Printer 7

What Is in the Box? ... 7
- Removing the Packing Material ... 8
- Repacking the Printer ... 9

Choosing a Location ... 10
Setting Switches ... 10
Connecting the Cables ... 12
Turning On the Printer ... 14
Loading and Changing the Receipt Paper ... 15
- Removing the Paper Roll ... 16
- Putting In the Paper Roll ... 17
- Advancing Paper ... 17

Putting In and Changing the Ribbon Cassette ... 18
- Removing the Ribbon Cassette ... 18
- Putting In the Ribbon Cassette ... 19

Printing on Forms or Checks ... 20
Validating and Verifying Checks ... 22
Testing the Printer ... 24
- Running the Print Test by Power Cycling the Printer ... 24
- Running the Print Test by Opening and Closing the Cover ... 24
- Sample Print Test ... 25

Paper Low Sensor 26

Chapter 3: Solving Problems 27

Printer Beeps Twice 27
Green LED Does Not Come On / Printer Will Not Print 27
Red LED Flashes 28
Red LED Is Constant 28
Slip or Forms Printing is Light 29
Receipt Printing is Light or Spotty 29
LED (Slip Table) Does Not Come On 30
Forms Skew or Catch 30
MICR Check Reader Not Reading Properly 30
Other Serious Problems 31
Contacting a Service Representative 31

Chapter 4: Diagnostics 33

Level 0 Diagnostics 33
Level 1 Diagnostics 34
- Setting Partial Cut Distance 36
- Setting Data Error and Data Buffer Options) 37
- Ignoring / Using the Carriage Return 38
- Checking and Adjusting the MICR Check Reader 39
- Verifying Read of MICR Characters 42
- Running the Data Scope Mode 43
- Testing the Slip and Receipt Stations 44

Level 2 Diagnostics 46
Level 3 Diagnostics 47
Print Test 47
- Running the Print Test by Power Cycling the Printer 47
- Running the Print Test by Opening and Closing the Cover 47
- Sample Print Test 48

Chapter 5: Communication 49

Communication Overview 49
- Interface 49
- Sending Commands 49

RS-232C Interface 50
- Print Speed and Timing 50
- XON / XOFF Protocol 51
- DTR / DSR Protocol 51
- RS-232C Technical Specifications 52
- Setting Extra RS-232C Options 54

Chapter 6: Commands 55

Command List 55
Printer Function Commands 55
Print Characteristics Commands 57
Station Select Commands 58
Graphics Commands 58
Printer Status Commands 58
Real Time Commands 59
Bar Code Commands 59
MICR Check Reader Commands 59
Command Descriptions 60
Printer Function Commands 60
Print Characteristics Commands 72
Station Select Commands 78
Graphics Commands 79
Printer Status Commands 83
Real Time Commands 90
Bar Code Commands 98
MICR Check Reader Commands 102
MICR Parsing 103
General Slip Handling 110

Appendix A: Specifications 113

Printing Specifications 113
Power Requirements 114
Environmental Conditions 114
Reliability 114
Dimensions and Weight 115
Density of Receipt Print Lines 115
Duty Cycle Restrictions (Printing Solid Blocks) 115

Appendix B: Print Characteristics 117

Character Size 117
Receipt Station 117
Slip Station 118
Print Zones 121
Receipt Station 121
Slip Station 122
Character Sets 122

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/NCR/7156 owners manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM