NCR 7194 Thermal Receipt Printer

Release 1.0

Service Guide

B005-0000-1098
Issue D

Table of Contents

Chapter 1: **Technical Specifications**

Reliability 1-1
Power Requirements 1-2
Environmental Conditions 1-3
Dimensions and Weight 1-4
Printing Specifications 1-5
Density of Receipt Print Lines 1-6
Duty Cycle Restrictions (Printing Solid Blocks) 1-7
Allowable Duty Cycle (measured over one minute of continuous printing) 1-8

Chapter 2: **Diagnostics and Configuration**

Startup Diagnostics 2-2
Runtime Diagnostics 2-3
Remote Diagnostics 2-4
Indicators 2-7
Printer Configuration 2-9
Configuring the Printer 2-11
Communication Interface 2-14
RS-232C Serial Interface Settings 2-14
Printer Emulations 2-16
Printer Settings and Functions 2-16
Enable or Disable Data Scope Mode 2-19
Printhead Resistance 2-21

Chapter 3: **Troubleshooting**

Service Level Troubleshooting 3-1
Printer Tone and Green LED 3-1

Printing Problems 3-2
Printer Does Not Function 3-5

Chapter 4: **Servicing the Printer**

Tools Required 4-1
Service Procedure Map 4-2
1, 2: Removing or Accessing the PC Control Board 4-3
Procedure 4-4
Re-installing the Control PC Board 4-7
3, 4: Removing the Options PC Board 4-9
Procedure 4-9
Re-installing the Options PC Board 4-10
5, 6: Removing the Rear Cover and Platen 4-11
Procedure 4-11
Re-installing the Rear Cover and Platen 4-12
7: Removing the Platen / Fixed Knife Carrier Assembly 4-13
Procedure 4-14
Fixed Knife Blade / Platen-Carrier Assembly Removal 4-15
Re-installing the Knife 4-15
8, 9, 10, 11: Removing the Top Cover Assembly, Paper Feed Rod / Light Pipe, Reset Rod, and Paper Feed Button 4-16
Procedure (See illustration next page.) 4-16
R 4-18
12: Removing the Paper Low Sensor / Mount 4-19
Procedure (See illustration next page.) 4-19
Re-installing the Paper Low Sensor / Mount 4-21
13: Removing the Thermal Mechanism 4-22
Procedure 4-22
Re-installing the Thermal Mechanism 4-25
14, 15, 16: Removing the Paper Out Switch, Knife Home Switch, and Cover Open Switch 4-26
Procedure 4-26

Re-installing the Paper Out Switch, Knife Home Switch, and Cover Open Switch 4-27
17: Removing the Rotating Knife Blade 4-28
Procedure 4-28
Re-installing the Rotating Knife Blade 4-29
Cleaning the Printer 4-30
Cleaning the Printhead 4-30

Revision Record

Issue	Date	Remarks
A	Nov 98	First issue
B	Mar 99	Updated
C	June 99	Minor updates
D	June 00	Updates

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/NCR/7194 service manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM