REV : 01
JULY 31, 1999

TP SERIES

Service Manual

CAS CORPORATION

CONTENTS

CHAPTER- I THE GENERAL INTRODUCTIONS

A....PREFACE 3
B....THE PRECAUTIONS 3
C....SPECIFICATIONS 4
D....SEALING METHOD 5

CHAPTER- II THE CALIBRATIONS

A....SET THE CALIBRATION MODE 6
A.1..SPAN CALIBRATION 7
A.2..PERCENT CALIBRATION 8
A.3..TO CONFIRM THE SPAN AND TO DO FINE TRIMMING 8
A.4..HOW TO RETURN TO NORMAL MODE 8

CHAPTER-III THE PART REPLACEMENTS

A....REPLACEMENT OF THE LOAD CELL 10
A.1.. REPLACEMENT OF THE LOAD CELL 10
A.2.. CORRECTION OF THE ECCENTRICITY 10

CHAPTER-IV THE TRANSFORMER

A....THE TRANSFORMER 11

CHAPTER- V THE SCHEMATICS AND THE DIAGRAMS

A.... MAIN CIRCUIT DIAGRAM 12
B.... DISPLAY CIRCUIT DIAGRAM 13
C.... WIRING DIAGRAM 14
D.... PARTS LOCATION 16

CHAPTER-VI FULL PARTS LIST

A....FULL PARTS LIST 30

APPENDIX-I

A....INPUT CODE FOR THE DIGITAL MODULE 45
A.1.. INPUT FOR THE SOFT KEY CODES 45
A.2.. INPUT FOR WEIGHING CONDITION CODES 47
A.3.. THE SPAN CALIBRATION 47

APPENDIX-II DEVICE SPECIFICATIONS

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/CAS/TP-Series service manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM