ISHIDA BC-3000

Scale to Scale Communications

Setup Procedure
&
Operating Instructions

March 2006

PN 94561

BC-3000 Scale to Scale Communications

Overview 2
- Communication Cables 2
  - Scale to Scale 2
  - Scale to PC (RS-232) 2

Scale to Scale Communications with a Master Board 3
- System Configuration 3
- Additional Components 3
- Firmware 3
- Installing the Master Board (P-835) into a BC-3000 Master Scale 4
  - Master Board Kit Components (Part No 48744 or 48745) 4
  - Procedure 4
- Configuration Programming 6
  - Test Mode 6
  - Programming Mode 8
- Communication Settings 9
- Label Formats 9
- Chinese (Hong Kong) firmware (version C1312x) - Special RAM Clear 10
  - Background 10
  - Procedure 10
  - Notes 10

Scale to Scale Communications without a Master Board 11
- Overview 11
- Configuration 11
- Communication Cable 12
- Programming 12
- Operation 12
- Totals 12
- Errors 12
- Label Formats 12
- Miscellaneous 12

This is a “Table of Contents preview” for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

http://the-checkout-tech.com : the biggest supplier of cash register and scale manuals on the net