

SHARP PROGRAMMING MANUAL

CODE : 00ZXEA41SUPME



LEAD-FREE SOLDER MODEL

ELECTRONIC CASH REGISTER

MODEL XE-A41S

CONTENTS

CHAPTER 1. MASTER RESET AND PROGRAM RESET 1 - 1

CHAPTER 2. PROGRAM (PGM2/PGM1) MODE 2 - 1

CHAPTER 3. OP X/Z, X1/Z1, X2/Z2 MODE..... 3 - 1

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*