

ELECTRONIC CASH REGISTER

TOWA NT-1071

OPERATING INSTRUCTION MANUAL

CONTENTS

1. SYSTEM CLEAR	1
2. CONTROL LOCK	1
3. DISPLAY	1
4. KEYBOARD	1
5. PROGRAMMING	
5-1. Main Flag Programming	3
5-2. Date Programming	4
5-3. Department Programming	4
5-4. Tax Programming	4
5-5. —% Rate Programming	6
6. REGISTRATION	7
7. X, Z REPORT	10
8. REPLACING PAPER ROLL	11
9. REPLACING INK ROLLER	11
10. EMERGENCY DRAWER OPENING	11
11. MACHINE FAILURE	12
12. SPECIFICATION	12