



DBII-LCD SERVICE MANUAL

< Table of Contents >

1.	Introduction	3
1.1.	Preface	3
1.2.	Precaution	3
1.3.	Specification	4
1.4.	Sealing Method.....	5
2.	Calibration	6
2.1.	General Calibration.....	6
2.1.1.	C4 Setting	7
2.1.1.1.	C4-1 Setting.....	7
2.1.1.2.	C4-2 Setting.....	7
2.1.1.3.	C4-3 Setting.....	7
2.1.1.4.	C4-4 Setting.....	8
2.1.1.5.	C4-5 Setting.....	8
2.1.2.	SPAN Calibration Setting (C-3).....	9
2.1.3.	Gravity Constant Value Setting (C-9)	9
2.1.4.	Calibration factor Setting (C-10).....	10
2.1.5.	Displaying Real A/D Value (C-5)	10
2.1.6.	Percent Calibration (C-7)	11
2.1.7.	Battery Calibration (C-8)	11
3.	The Schematics and Diagram.....	12
3.1.	System Block Diagram.....	12
3.2.	Circuit Diagram	오류! 책갈피가 정의되어 있지 않습니다.
3.2.1.	MAIN	오류! 책갈피가 정의되어 있지 않습니다.
3.2.2.	DISPLAY & MODULE	오류! 책갈피가 정의되어 있지 않습니다.
4.	Exploded View.....	13
5.	Part Location.....	15
	Main PCB Part Location(TOP).....	16
	Main PCB Part Location(BOTTOM).....	17
	TERMINAL PCB.	18
6.	Error Messages & Solution.....	19
7.	Part List.....	20

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*