

---

**METROLOGIC INSTRUMENTS, INC.**

**IS4320 ScanGlove**

**Programming Guide**

---

## Table of Contents

---

Programming the Scanner .....	1
Enter Program Mode .....	2
Recall Defaults .....	2
Laser Activation Range .....	3
Laser Operation .....	4
Same Symbol Re-Scan .....	5
Beeper Tones .....	6
Audible Indicators for Communication Timeouts .....	7
RS-232 Interface .....	8
RS-232 Parameter - Baud Rate .....	8,9
RS-232 Parameter - Parity .....	10
RS-232 Parameter - Data Bits .....	11
RS-232 Parameter - Hardware Handshaking .....	12
RS-232 Parameter - Software Handshaking .....	13
RS-232 Parameter - Intercharacter Delay .....	14
RS-232 Parameter - Scanning Control (DTR Signal) .....	15
Record Header/Terminator Select .....	15-17
RS-232 Parameter - UPC/EAN Identifiers .....	18
Light Pen Options .....	19
Code Type Selections .....	20,21
Minimum Code Length for All Code Types .....	22

UPC/EAN Code .....	22
UPC-A Options .....	23
UPC-E Options .....	24
Supplemental UPC Options .....	25
Code 39 .....	26, 27
Codabar .....	27
Interleaved 2 of 5 (ITF) .....	28
Interleaved 2 of 5 (ITF) Symbol Lengths .....	29-32
MSI - Plessey Check Digit .....	32, 33
Test Modes .....	34
Special Features .....	35, 36
Reserved Codes .....	37-41
Disclaimer .....	42
Index .....	43, 44

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Metrologic/IS4320 ScanGlove programming man](https://the-checkout-tech.com/manuals/Metrologic/IS4320%20ScanGlove%20programming%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)