



METROLOGIC INSTRUMENTS, INC.
MS6720 Hand-Held Laser Scanner
Installation and User's Guide



TABLE OF CONTENTS

Introduction.....	1
Scanner and Accessories.....	2
Quick Start.....	3
Operational Test.....	4
MS6720 Installation: Powered by External Power Supply.....	5
MS6720 Installation: Powered by Host Device.....	6
MS6720-47 Keyboard Wedge Installation to the PC.....	8
MS6720 Optional Stands.....	9
Scanner Parts.....	11
Audible Indicators.....	12
Failure Modes.....	13
Visual Indicators.....	14
Scanner Labels.....	15
Maintenance.....	15
Depth of Field Specifications	
Normal Depth of Field.....	16
Short Depth of Field.....	17
Extended Depth of Field.....	18
Optional Depth of Field.....	19
Normal Depth of Field.....	20
Short Depth of Field.....	20
Scan Pattern Specifications	
Projection Axis.....	21
Omnidirectional Scan Volume.....	21
Cross-Sectional Scan Pattern.....	22
Troubleshooting Guide.....	23
Applications and Protocols.....	28
Appendix A	
Design Specifications.....	29
Appendix B	
Default Settings.....	31

TABLE OF CONTENTS

Appendix C	
Pin Assignments for the Coil Cable.....	35
Pin Assignmentsf or the MCA951.....	36
Pin Assignmentsf or the MS6720-47 Keyboard Wedge Cable.....	37
Appendix D	
Limited Warranty	38
Appendix E	
Notices.....	39
Appendix F	
Patents	41
Index	42

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Metrologic/MS6720 user manual.html](https://the-checkout-tech.com/manuals/Metrologic/MS6720%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)