
METROLOGIC INSTRUMENTS, INC.

**MS951 Hand-Held Laser Scanner
and MS951 Hand-Held Scanner
with Built-in PC
Keyboard Wedge Interface**

Installation and User's Guide

Table of Contents

Introduction	1, 2
Scanner and Accessories	3
Quick Start	4
Operational Test	5
Scanner Installation: Powered by External Power Supply	6
Scanner Installation: Powered by Host Device	7
Scanner Installation to the PC (Scanner with Built-in PC Keyboard Wedge Interface)	8, 9
Configuration of the MS951/MS961-48 Scanner	10
Version "11" 46X Interface	11
Configuring the Scanner with 46XX Interface	12
Operating Characteristics	12
Configuring the IBM 46XX	12
IBM 4683 and 4693 Terminals Driven by a 46XX Store Controller Running 4680.OS or 4690.OS	13
IBM 4684 and 4694 Systems	13
Parts of the MS951	14
Components of the MS900 Series Stand	15
Installation of the MS900 Series Stand	15, 16
Audible Indicators	17
Visual Indicators	18-21
Labels	22
IR Sensor Activation	23
Scan Field	24

MS951 - Depth of Field and Symbol Specification	25, 26
MS961 - Depth of Field and Symbol Specification	27, 28
Maintenance	29
Applications and Protocols	29
Appendix A	
MS951 Hand-Held Laser Scanner Specifications	30, 31
MS951 Hand-Held Laser Scanner w/KBW Specifications ...	32, 33
Appendix B	
Default Settings	34-38
Appendix C	
Pin Assignments for the Coil Cable	39
Pin Assignments for the MCA (DEC9S)	40
Pin Assignments for the 5-pin DIN and 6-pin DIN (KBW)	41
Appendix D	
Warranty and Disclaimer	42, 43
Appendix E	
Notices	44, 45
Appendix F	
Patents	46
Index	47, 48

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*