



METROLOGIC INSTRUMENTS, INC.  
MetroSelect<sup>®</sup> Single-Line  
Configuration Guide

---

## TABLE OF CONTENTS

---

<b>Introduction .....</b>	<b>1</b>
<b>Bar Code Configuration Methods</b>	
Single-Code Method.....	1
Multi-Code Method .....	2
<b>Need to Start Over?.....</b>	<b>2</b>
<b>Code Types and Decode Rules</b>	
UPC/EAN .....	3
Code 128.....	4
Code 39.....	4
2 of 5 Codes .....	6
Codabar.....	9
Code 93.....	9
Code 11.....	9
Telepen .....	10
Plessey Codes .....	10
Additional Decode Features .....	11
Configurable Code Lengths.....	12
<b>Supplements .....</b>	<b>14</b>
<b>RSS Bar Code Implementation</b>	
RSS Limited Bar Codes.....	20
RSS Expanded Bar Codes .....	20
<b>ISBT Code 128 Implementation</b>	
Configuration Mode Bar Codes .....	21
Concatenation Configuration Mode Bar Codes .....	22
Pre-Defined Concatenation Configuration Mode Bar Codes .....	22
User-Defined Concatenation Configuration Mode Bar Codes .....	23
<b>Communications .....</b>	<b>25</b>
<b>Scanner Operation</b>	
Configuration Mode Options.....	26
Scan Buffers.....	26
Redundant Scans.....	27

## TABLE OF CONTENTS

---

Miscellaneous Decode Features .....	27
Same Symbol Timeouts .....	28
LED Options .....	28
Beeper Options .....	29
Data Transmission Delays.....	31
Communication Timeout Options .....	32
Host Scanner Commands .....	33
Test Modes.....	35

### **Prefixes/Suffixes**

User Configurable Prefixes, All Data .....	36
User Configurable ID Characters, Code Specific .....	37
Standard Prefix Characters .....	39
Standard Suffix Characters .....	41
Longitudinal Redundancy Check.....	42
Block Check Character.....	42
Character Replacements.....	43
User Configurable Suffixes, All Data .....	44
Special Formats .....	45

### **Code Formatting**

UPC/EAN Formatting .....	46
Codabar Formatting .....	48
Code 39 Formatting.....	49
Code 11 Formatting.....	49
Telegen .....	49
Plessey.....	50
2 of 5 Code Formatting.....	50

### **RS232**

Parity Features .....	51
Baud Rate .....	51
Data/Stop Bits .....	52
Hardware Handshaking .....	52
Software Handshaking .....	54
Miscellaneous.....	55

---

## TABLE OF CONTENTS

---

<b>Keyboard</b>	
Enable Keyboard Emulation .....	56
Country/Scan Code Table Selects .....	56
Keyboard/System Type .....	57
'Dumb' Terminal Selections .....	58
Special Keyboard Features .....	59
InterScan Code Delays .....	61
Control Sets.....	61
<b>OCIA .....</b>	<b>63</b>
<b>Light Pen Parameters.....</b>	<b>64</b>
Set Narrow Element Width .....	65
<b>MS9520/9540-00 Laser Emulation Mode.....</b>	<b>66</b>
<b>IBM 46xx Configuration</b>	
IBM Port .....	67
IBM Reserve Codes .....	67
<b>USB.....</b>	<b>68</b>
<b>Code Bytes Usage</b>	
Code Bytes 0-9.....	70
Reserved Codes.....	71
Code Type Table .....	71
ASCII Reference Table.....	72
Extended Key Code Reference Table .....	76
<b>MS9520 Voyager® &amp; MS9540 VoyagerCG® Series</b>	
Activation Range .....	78
Stand Scan Modes .....	78
CodeGate® Status .....	78
Laser/Scan Modes .....	79
Same Symbol Time Outs.....	80
<b>MS9524 &amp; MS9544 VoyagerPDF® Series</b>	
PDF CodeGate Status.....	81
MicroPDF and Composite Code Handling .....	81

## TABLE OF CONTENTS

---

<b>MS9535 VoyagerBT® .....</b>	<b>83</b>
<b>MS9535-5M VoyagerBT® .....</b>	<b>85</b>
Inventory Quantity Bar Codes .....	87
<b>IS4125 / IS4225 Scan Engines .....</b>	<b>88</b>
 <b>Miscellaneous Features</b>	
Custom Defaults.....	89
Serial Program Mode .....	90

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net