



**QUICKSCAN™**  
*6000/6000 plus*

## *Handheld Laser Scanner*



***PROGRAMMING GUIDE***

# Contents

## Introduction

Understanding the Basics .....	1
Integrating Peripherals With Host Systems .....	1
Changing Interfaces .....	2
Customizing Your Scanner Operation .....	4
Programming Overview .....	5
What Is Programming Mode? .....	5
How To Program Using Bar Codes .....	5
The Programming Session .....	6
Scanner Response When In Programming Mode .....	6
If You Make a Mistake... ..	7
Return to Factory Settings .....	7
Where To Go From Here .....	8

## Interface Selection

### IBM

IBM 4683/84 • 4693/94 Port 5B Interface Selection .....	9
IBM 4683/84 • 4693/94 Port 9A, 9B, 9C, 9E I/F Selection .....	10
IBM 4682/92 Port E Interface Selection .....	11

### OCIA

PSC OCIA1 Interface Selection .....	12
NCR OCIA Eight Bit (short format) Interface Selection .....	12
NCR OCIA Nine Bit (long format) Interface Selection .....	12
SNI OCIA Interface Selection .....	12
OCIA Options .....	13

### Wand Emulation

Wand Emulation Interface Selection .....	14
--	----

### RS-232

RS-232 Interface Selection .....	16
SNI RS-232 Interface Selection .....	16
Hardware Control .....	19
Software Control .....	20
RS-232 ACK/NAK Options .....	21

### Keyboard Wedge

PC Keyboard Wedge Interface Selection .....	24
PC Keyboard Wedge Interface Selection—continued .....	25
Connect to a Laptop/No Keyboard Attached .....	26
Caps Lock .....	27
Country Mode .....	28
Intercharacter Delay .....	30

Label Transmit Format Configuration Items .....	32
Prefix & Suffix .....	32
Non-Symbology Specific Items .....	34
ASCII Character Set .....	38
Symbology-Specific Label I.D. ....	39

## Symbologies

Symbology Options Overview .....	47
Symbology Selection .....	49
UPC/EAN Options .....	52
UPC/EAN Expansion .....	53
UPC/EAN Add-Ons .....	54
C128 and Custom Add-Ons .....	54
Price/Weight Check Digit .....	55
Code 39 Options .....	58
Code 128 Options .....	62
Interleaved 2 of 5 .....	63
Check Digit and Variable Length Label Selections .....	64
Standard 2 of 5 .....	67
Check Digit and Variable Length Label Selections .....	68
Setting Standard 2 of 5 Fixed and Minimum Label Lengths .....	69
Codabar Options .....	72
Codabar Check Digit & Variable Length .....	73
Codabar Start/Stop Character .....	74
Codabar Fixed Length .....	75
MSI/Plessey	
MSI/Plessey Check Digit .....	77
MSI/Plessey Fixed Length .....	78

## General Features

Good Read Beeper Settings .....	80
Read Verification .....	82
Low Power Mode .....	85
Debug Mode .....	86
AutoSense® Stand Mode .....	86

## Appendix A

Host Programming .....	87
Creating MultiFunction Labels .....	87
Need More Information? .....	87

## Appendix B

Sample Bar Codes .....	88
------------------------	----

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/PSC/QuickScan-6000 programming manual.html](https://the-checkout-tech.com/manuals/PSC/QuickScan-6000%20programming%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://the-checkout-tech.com)