

---

# SERVICE MANUAL


---

ELECTRONIC CASH REGISTER

**110CR/PCR250** (EX-266)

**150CR** (EX-267)

JAN. 1995



110CR-S

Printer Model : M42V

**CASIO®**

## CONTENTS

	Page
<b>1.FEATURES</b> .....	<b>1</b>
<b>2.SPECIFICATIONS</b> .....	<b>1</b>
<b>3.OPTION</b> .....	<b>2</b>
<b>4.MAC OPERATION</b> .....	<b>2</b>
<b>5.BLOCK DIAGRAM</b> .....	<b>3</b>
<b>6.CIRCUIT EXPLANATIONS</b> .....	<b>4</b>
6-1. Power supply circuit .....	4
6-2. Reset circuit .....	5
6-3. Data communication between CPU and EEPROM .....	6
6-4. Printer drive circuit .....	8
6-5. Pin description .....	9
<b>7.DISASSEMBLY</b> .....	<b>10</b>
7-1. To open the upper case .....	10
7-2. To remove the Main PCB .....	10
7-3. To remove the keyboard ass'y .....	10
<b>8. DIAGNOSTOC OPERATIONS</b> .....	<b>11</b>
<b>9. IC DATA</b> .....	<b>16</b>
9-1. LB1268 .....	16
9-2. S-80728AN-Z .....	16
<b>10.CIRCUIT DIAGRAM</b> .....	<b>17</b>
<b>11.PCB LAYOUT</b> .....	<b>28</b>
<b>12. PARTS LIST</b> .....	<b>29</b>

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)