

ELECTRONIC CASH REGISTER

CASIO 120ER

OPERATOR'S INSTRUCTION MANUAL

CASIO®

INDEX

1	NOMENCLATURE	3
1-1.	MODE SWITCH	4
1-2.	DISPLAY	4
1-3.	KEYBOARD	5
1-4.	CASH DRAWER	6
1-5.	KINDS OF KEY APPLICATIONS	7
2	OPERATION	7
2-1.	BEFORE STARTING OPERATION	7
2-2.	BASIC OPERATION PROCEDURE	8
3	PROGRAMMING	8
3-1.	PRESETTING THE DATE AND TIME	8
3-2.	PRESETTING TAX STATUS FOR DEPARTMENTS AND REDUCTIONS	9
3-3.	PRINTING CONTROL STATUS	10
3-4.	TABLE TAX PROGRAMMING	10
3-5.	READING PRESET DATA	14
4	REGISTER OPERATION	15
4-1.	SINGLE ITEM SALE	15
4-2.	MULTIPLE ITEM SALE	15
4-3.	CHANGE CALCULATION	16
4-4.	REPEAT CALCULATION	17
4-5.	MULTIPLICATION CALCULATION	18
4-6.	REDUCTION CALCULATION	19
4-7.	MANUAL TAX ENTRY	21
4-8.	CHARGE SALES	22
4-9.	PROCESSING RETURNED GOODS	22
4-10.	EXCHANGE	23
4-11.	REFERENCE NUMBERING	23
4-12.	MAKING CORRECTIONS	24
5	READ AND RESET	27
5-1.	READ	27
5-2.	RESET	28
6	PAPER ROLL REFILLING	29
7	INK ROLLER REPLACEMENT	30
8	IF THE MACHINE IS INOPERATIVE	30
9	SPECIFICATIONS	31

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)