


MASTER.


ELECTRONIC CASH REGISTER

# 240CR

OPERATOR'S INSTRUCTION MANUAL



4-Department with S drawer



4-Department with M drawer

- Eu
- Di
- U.K.

# CASIO

# Contents

<b>Introduction .....</b>	<b>2</b>
Unpacking the register .....	2
<b>Getting Started .....</b>	<b>6</b>
Remove the cash register from its box .....	6
Remove the tape holding parts of the cash register in place .....	6
Install the three memory backup batteries .....	6
Plug the cash register into a wall outlet .....	8
Insert the mode key marked "PGM" into the Mode Switch .....	8
Turn the mode key to the "REG" position .....	8
Install receipt/journal paper .....	8
To load 1-ply paper for printing of receipts .....	9
To load 1-ply paper for printing of journal .....	10
To load 2-ply paper for printing of receipts .....	11
Set the date .....	12
Set the time .....	12
Select printouts receipt or journal .....	12
Tax table programming .....	13
Programming automatic tax calculation .....	13
Programming tax calculations (without special rounding) .....	13
Programming tax calculations (with special rounding) .....	16
Setting an advertisement in the rear promotional panel .....	17
<b>Introducing 240CR .....</b>	<b>18</b>
General guide .....	18
Mode key .....	18
Displays .....	19
Drawer, Mode switch .....	20
Keyboard .....	21
<b>Basic Operations and Setups .....</b>	<b>22</b>
How to read the printouts .....	22
How to use your cash register .....	23
Displaying the time and date .....	24
Preparing coins for change .....	24
Preparing and using department keys .....	25
Registering department keys .....	25
Programming department keys .....	26
Registering department keys by programming data .....	27
Preparing and using PLUs .....	28
Programming PLUs .....	28
Registering PLUs .....	29
Preparing and using discounts .....	30
Programming discounts .....	30
Registering discounts .....	31

Preparing and using reductions .....	32
Programming for reductions .....	32
Registering reductions .....	33
Printing VAT break downs .....	34
Registering charge and check payments .....	35
Registering returned goods in the REG mode .....	36
Registering returned goods in the RF mode .....	37
Registering money received on account .....	38
Registering money paid out .....	38
Making corrections in a registration .....	39
No sale registration .....	42
Printing the daily sales RESET report .....	43
<b>Convenient Operations and Setups .....</b>	<b>44</b>
About the clerk control function .....	44
About post-finalization receipt .....	45
Programming general printing control .....	46
Programming READ/RESET report printing control .....	47
Programming compulsory, clerk control function and other features .....	48
Setting/editing the store telephone number .....	49
Setting a store/machine number .....	50
High digit limitation for departments .....	50
Single-item-sales for departments and PLUs .....	51
Registering sub-departments .....	52
Registering discounts and premiums .....	55
Other programmable options .....	57
Calculator functions .....	58
Printing READ/RESET reports .....	60
Printing the cash register's program .....	66
<b>Troubleshooting .....</b>	<b>68</b>
When an error occurs .....	68
When the register does not operate at all .....	69
In case of power failure .....	70
When the L sign appears on the display .....	70
<b>User Maintenance and Options .....</b>	<b>71</b>
To replenish stamp ink .....	71
To replace the ink ribbon .....	71
To replace journal paper .....	72
To replace receipt paper .....	73
Options .....	73
<b>Specification .....</b>	<b>74</b>
<b>Index .....</b>	<b>75</b>

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)