

ELECTRONIC
CASH
REGISTER

CE-2108

OPERATOR'S INSTRUCTION MANUAL



FCC CI

CASIO®

CONTENTS

1	LOADING RECEIPT AND JOURNAL PAPER	3
	1-1 REMOVING PAPER ROLLS	3
	1-2 LOADING PAPER ROLLS	4
2	GENERAL GUIDE	5
	2-1 MODE CONTROL SWITCH AND KEYS	5
	2-2 DISPLAYS	6
	2-3 KEYBOARD	7
	2-4 PRINTER	8
	2-5 CASH DRAWER	8
3	PROGRAMMING	9
	3-1 PROGRAM 1 MODE (X MODE)	9
	3-2 PROGRAM 2 MODE (Z MODE)	11
	3-3 TAX TABLE PROGRAMMING	17
	3-4 READING ALL PRESET DATA	21
4	OPERATION	22
	4-1 OPERATIONAL PRECAUTIONS	22
	4-2 BASIC OPERATION PROCEDURE	22
	4-3 READING THE TIME AND DATE	22
5	REGISTRATION	23
	5-1 MAKING CHANGE	23
	5-2 SINGLE ITEM CASH SALE	23
	5-3 MULTIPLE ITEM CASH SALE WITH/WITHOUT CHANGE CALCULATION	25
	5-4 MANUAL TAX AND TAX SHIFT	28
	5-5 PARTIAL TENDER REGISTRATION	29
	5-6 DISCOUNT/PREMIUM	30
	5-7 REDUCTION	32
	5-8 RETURNED GOODS	33
	5-9 PAYMENT MEDIA OTHER THAN CASH	34
	5-10 RECEIVED ON ACCOUNT	35
	5-11 PAIDOUT	35
	5-12 MAKING CORRECTIONS	36
6	READ AND RESET OPERATIONS	37
	6-1 ISSUING REPORTS	37
	6-2 REPORT SAMPLES	40
7	CARING FOR THE PRINTER	42
	7-1 REPLENISHING THE STAMP INK	42
	7-2 REPLACING THE INK ROLL	42
8	TROUBLESHOOTING	43
9	ABOUT THE MEMORY PROTECTION BATTERY	43
10	OPTIONS	43
	10-1 WETPROOF COVER (MODEL WT-47)	43
11	SPECIFICATIONS	44

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)