

ELECTRONIC CASH REGISTER

CE-250

THANK YOU
YOUR RECEIPT
CALL AGAIN !

GROCERY
DAIRY
H.B.A.
FROZEN
FOOD
DELICATESSEN



OPERATOR'S INSTRUCTION MANUAL

Introduction & Contents	2
Unpacking the register	2
Getting Started	6
Remove the cash register from its box	6
Remove the tape holding parts of the cash register in place	6
Install the three memory backup batteries	6
Plug the cash register into a wall outlet	8
Insert the mode key marked "PGM" into the mode switch	8
Turn the mode key to the "REG" position	8
To set the ink ribbon	8
Install receipt/journal paper	9
To load 1-ply paper for printing of receipts	9
To load 1-ply paper for printing of journal	10
To load 2-ply paper for printing of receipts	11
Set the date	12
Set the time	12
Select printouts receipt or journal	12
Programming automatic tax calculation	13
Programming the U.S. tax table procedure	13
Introducing CE-250	18
General guide	18
Mode key, drawer, mode switch	18
Displays	20
Keyboard	22
Basic Operations and Setups	24
How to read the printouts	24
How to use your cash register	25
Displaying the time and date	26
Preparing coins for change	26
Preparing and using department keys	27
Registering department keys	27
Programming department keys	29
Registering department keys by programming data	30
Preparing and using PLUs	31
Programming PLUs	31
Registering PLUs	32
Preparing and using discounts	34
Programming discounts	34
Registering discounts	35
Preparing and using reductions	36
Programming for reductions	36
Registering reductions	37
Calculating the merchandise subtotal	38
Shifting taxable 1/2 status of an item	39
Registering charge and check payments	40

Registering returned goods in the REG mode	41
Registering returned goods in the RF mode	42
Registering money received on account	43
Registering money paid out	43
Making corrections in a registration	44
No sale registration	46
Printing the daily sales reset report	47
Convenient Operations and Setups	48
Clerk control function, Post-finalization receipt format, General printing control, Compulsory, Machine features	48
About the clerk control function	48
About post-finalization receipt	49
Programming general printing control	50
Programming compulsory and clerk control function	51
Programming read/reset report printing control	52
Setting a store/machine number	52
Programming to clerk	53
Programming descriptors and messages	54
Programming report descriptor, grand total, special character, report title, receipt message and clerk name	54
Programming department key descriptor	57
Programming PLU descriptor	58
Programming function key descriptor	59
Entering characters	60
Department key programming	62
PLU feature programming	64
Percent key feature programming	69
Currency exchange programming	72
Other function key programming	75
Calculator functions	76
Printing read/reset reports	78
Reading the cash register's program	84
Troubleshooting	88
When an error occurs	88
When the register does not operate at all	89
In case of power failure	90
When the L sign appears on the display	90
User Maintenance and Options	91
To replace the ink ribbon	91
To replace journal paper	92
To replace receipt paper	93
Specifications	94
Index	95

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)