

SERVICE MANUAL

(without price)

ELECTRONIC CASH REGISTER

CE-300 (EX-247)

JANUARY 1997



Printer Model : MD-910

CASIO.[®]

INDEX

CONTENTS

	Page
1. SPECIFICATIONS	1
2. INITIALIZE (MAC) OPERATION	1
3. BLOCK DIAGRAM	
3-1. PCB connection	2
3-2. Block diagram (circuit)	3
4. CIRCUIT EXPLANATION	
4-1. Power supply circuit	4
4-2. CPU (uPD78052GC-093-3B9)	5
4-3. Display controller (uPD16312GB-3B4)	7
4-4. Initialize IC (Reset circuit)	8
4-5. Power down detection circuit (PWD)	8
4-6. Address latch circuit	8
4-7. RAM / ROM bank selection circuit	9
4-8. Head drive circuit for printer	10
4-9. Vpp sensor circuit	11
4-10. Power supply circuit for display	11
5. DIAGNOSTIC	
5-1. To start the diagnostic program	12
5-2. Check item	12
5-3. Operation of each test	12
5-4. To exit the diagnostic test	17
6. ERROR CODE	
6-1. Operation error code	18
6-2. System lock code	19
7. IC DATA	
1. TC74HC00AP	20
2. TC74HC08AP	20
3. TC74HC138	20
4. TC74HC367AP	21
5. TL431CLPB	21
6. TC74HC373AP	21
7. S-80745 / S-80719	22
8. M5237L	22
9. MAX232	22
8. PCB LAYOUT	23
9. CIRCUIT DIAGRAMS	25
10. PARTS LIST	41

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/casio/CE-300 service manual.html](https://the-checkout-tech.com/manuals/casio/CE-300%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)