

SERVICE MANUAL

(without price)

ELECTRONIC CASH REGISTER

CE-T300 (EX-479A*)

APR. 2000



Printer Model : LTP4242B-C432

CASIO[®]

CONTENTS

CE-T300	Page
1. SPECIFICATIONS	1
2. INITIALIZE (MAC) OPERATION	3
3. F-INIT (FMAC) OPERATION	3
4. BLOCK DIAGRAM	4
5. TO OPEN THE UPPER CASE	6
6. CIRCUIT EXPLANATION	8
6-1. Power supply circuit	8
6-2. Reset and power down circuit	9
6-3. CPU description	10
6-4. Memory chip selection circuit	12
6-5. Flash ROM1 address circuit	13
6-6. Memory map	13
6-7. Printer drive circuit	14
6-8. RS232C port COM1 circuit	15
6-9. Keyboard selection switch (Not mounted for CE-T300)	15
6-10. Flash ROM pack circuit (Memory Cassette RAC-9)	15
6-11. To mount optional circuit	16
1) Clerk key circuit	16
2) Multi-drawer circuit	18
3) Paper near end sensor circuit	19
7. DIAGNOSTIC OPERATION	20
7-1. To start the diagnostic program	20
7-2. Check item	20
7-3. Operation of each test	20
7-4. Switch status test	21
7-5. Individual function test	22
7-6. To exit the diagnostic mode	32
8. ERROR CODE LIST	33
9. IC DATA	34
10. PCB LAYOUT	45
11. CIRCUIT DIAGRAM	47
12. PARTS LIST	65

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/casio/CE-T300 service manual.html>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)