

PERSONAL CASH REGISTER

PCR-208

OPERATOR'S INSTRUCTION MANUAL



FCC **CI**

CASIO®

CONTENTS

	UNPACKING	1
1	PROGRAMMING	4
	1-1 PROGRAM 1 MODE (X MODE)	4
	1-2 PROGRAM 2 MODE (Z MODE)	6
	1-3 TAX PROGRAM	10
	1-4 READING ALL PRESET DATA	11
2	OPERATION	19
	2-1 OPERATIONAL PRECAUTIONS	19
	2-2 BASIC OPERATION PROCEDURE	19
	2-3 READING THE TIME AND DATE	19
3	REGISTRATION	20
	3-1 MAKING CHANGE	20
	3-2 SINGLE ITEM CASH SALE	20
	3-3 MULTIPLE ITEM CASH SALE WITH/WITHOUT CHANGE CALCULATION	22
	3-4 TAX SHIFT	23
	3-5 DISCOUNT/PREMIUM	24
	3-6 REDUCTION	26
	3-7 RETURNED GOODS	27
	3-8 PAYMENT MEDIA OTHER THAN CASH	28
	3-9 PARTIAL TENDER REGISTRATION	29
	3-10 RECEIVED ON ACCOUNT	30
	3-11 PAIDOUT	31
	3-12 MAKING CORRECTIONS	31
4	READ AND RESET OPERATIONS	32
	4-1 ISSUING REPORTS	32
	4-2 REPORT SAMPLES	34
5	TROUBLESHOOTING	36
6	ABOUT THE MEMORY PROTECTION BATTERY	36
7	OPERATIONAL CHECK FLOW	37
8	SPECIFICATIONS	38
9	GENERAL GUIDE	39
	9-1 MODE CONTROL SWITCH AND KEYS	40
	9-2 DISPLAYS	41
	9-3 KEYBOARD	42
	9-4 PRINTER	43
	9-5 CASH DRAWER	43
10	MACHINE RESET	44
11	IMPORTANT	45
12	LOADING RECEIPT OR JOURNAL PAPER	46
	12-1 LOADING THE PAPER ROLL	46
	12-2 LOADING 2-PLY PAPER ROLL	47
13	PRINTER MAINTENANCE	48
	13-1 STAMP INK REPLENISHMENT	48
	13-2 REPLACING THE INK RIBBON	48

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)