


PERSONAL CASH REGISTER

PCR-330

OPERATOR'S INSTRUCTION MANUAL



FCC CI

CASIO

CONTENTS

	CONTENTS	1
1	PROGRAMMING	,
	1-1 PROGRAM 1 MODE (X MODE)	4
	1-2 PROGRAM 2 MODE (Z MODE)	2
	1-3 TAX PROGRAM	•
	1-4 READING ALL PRESET DATA	ະ ວດ
2	OPERATION	. 20
ىت	2-1 OPERATIONAL PRECAUTIONS	. 21
	2-2 BASIC OPERATION PROCEDURE	. ZI
3	REGISTRATION	. 21
ب	3-1 READING THE TIME AND DATE	. 21
	3-2 MAKING CHANGE	. 22
	3-3 SINGLE ITEM CASH SALE	. 22
	3-4 MULTIPLE ITEM CASH SALE WITH/WITHOUT CHANGE CALCULATION	. 23
	3-5 TAX SHIFT	. 26
	3-6 DISCOUNT/PREMIUM	. 30
	3-7 REDUCTION	. UI
	3-8 RETURNED GOODS	. აა აგ
	3-9 PAYMENT MEDIA OTHER THAN CASH	. 34 35
	3-10 PARTIAL TENDER REGISTRATION	38
	3-11 RECEIVED ON ACCOUNT	37
	3-12 PAIDOUT	37
	3-13 VALIDATION SLIP PRINTING	38
	3-14 MAKING CORRECTIONS	39
4	READ AND RESET OPERATIONS	
ш	4-1 ISSUING REPORTS	40
	4-2 REPORT SAMPLES	42
5	TROUBLESHOOTING	
6	ABOUT THE MEMORY PROTECTION BATTERY	
	OPERATIONAL CHECK FLOW	
7		
8	SPECIFICATIONS	
9	GENERAL GUIDE	
	9-1 MODE CONTROL SWITCH AND KEYS	
	9-2 CLERK BUTTONS	49
	9-3 DISPLAYS	
	9-4 MICRO-TOUCH KEYBOARD	
	9-5 PRINTER9-6 CASH DRAWER	
10	MACHINE RESET	
11	IMPORTANT	
11 12	LOADING RECEIPT OR JOURNAL PAPER	
-	12-1 LOADING THE PAPER ROLL	
	12-2 LOADING 2-PLY PAPER ROLL	
13	PRINTER MAINTENANCE	
	13-1 STAMP INK REPLENISHMENT	58
	13-2 REPLACING THE INK RIBBON	58

Click here to download the full manual at THE-CHECKOUT-TECH.COM