# QT-2100

## Versatile Intelligent Terminal

# Installation & Down Recovery Manual

Version 1.0 February 2002




CASIO

**1. System installation ..... I-6**

1-1. How to load IPL (Initial Program Loading) ..... I-6

1-1-1. From PC to QT-2100 terminal via RS-232C ..... I-6
1-1-2. From one QT-2100 to QT-2100 terminals via inline ..... I-7
1-1-3. From CF card to QT-2100 terminal ..... I-7

1-2. How to install QT-2100 system ..... I-8

1-2-1. QT-2100 stand alone system (with printer) ..... I-8
1-2-2. QT-2100 master/satellite system (with local printer) ..... I-8
1-2-3. QT-2100 master/satellite system (with remote printer) ..... I-9
1-2-4. Printer DIP switch configuration ..... I-10

**2. System down and recovery ..... I-11**

2-1. Measures to prevent trouble ..... I-12

2-2. Master terminal failure ..... I-13

2-2-1. Check tracking master terminal failure ..... I-13
2-2-1-1. Detection of check tracking master terminal failure ..... I-13
2-2-1-2. Master failure during check tracking operation ..... I-14
2-2-2. Remote printer failure ..... I-15
2-2-2-1. Detection of remote printer failure ..... I-15
2-2-2-2. Master printer failure during printing on remote printer ..... I-15

2-3. Recovery processing ..... I-16

2-3-1. Master/backup master down detection ..... I-16
2-3-2. When both master and backup master go down ..... I-16

2-4. Master failure during X/Z collection/consolidation or terminal data transfer ..... I-16

2-5. Satellite terminal down ..... I-16

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/cashregisters/Casio_QT-2100_installation_and_down_recovery_manual.html

Checkout our free online Keysheet Maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

**THE-CHECKOUT-TECH.COM**