

QT-6100

Touch Screen Smart Terminal

Installation & Down Recovery Manual

Version 1.0 June 2008

1. System installation	I-4
1-1.How to load IPL (Initial Program Loading)	I-4
1-1-1. From PC to a terminal via RS-232C	I-4
1-1-2. From CF card to a terminal	I-5
1-2.How to install the system	I-6
1-2-1. Stand alone system (with external printer / slip printer)	I-6
1-2-2. Master/satellite system with external (local) printer	I-6
1-2-3. Master/satellite system with external (remote) printer	I-7
1-2-4. External printer DIP switch configuration	I-8
2. System down and recovery	I-9
2-1.Measures to prevent trouble	I-10
2-2.Master terminal failure	I-11
2-2-1. Check tracking master terminal failure	I-11
2-2-1-1. Detection of check tracking master terminal failure	I-11
2-2-1-2. Master failure during check tracking operation	I-12
2-2-2. Remote printer failure	I-13
2-2-2-1. Detection of remote printer failure	I-13
2-2-2-2. Master printer failure during printing on remote printer	I-13
2-3.Recovery processing	I-14
2-3-1. Master/backup master down detection	I-14
2-3-2. When both master and backup master go down	I-14
2-4.Master failure during X/Z collection/consolidation or terminal data transfer	I-14
2-5.Satellite terminal down.....	I-14

To prevent malfunctions caused by the weak batteries, charge the memory protection batteries for over 12-hours before installation or after a longtime vacation (over 30 days).

- **Before installation, initialize the terminal and leave it turn on over 12-hours.**
- **After a longtime vacation, initialize the terminal and restore the program data if the terminal is in malfunction, and leave it turn on over 12-hours.**
- **Over 48-hours charging makes the batteries fully charged.**

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)