QT-6600

Touch Screen Smart Terminal

Installation & Down Recovery Manual

Version 1.11 May 2010



CASIO

1.	. System installation	I-4
	1-1.How to load IPL (Initial Program Loading)	I-4
	1-1-1. From CF card to a terminal	I-5
	 1-2-1. Stand alone system (with external printer / slip printer) 1-2-2. Master/satellite system with external (local) printer 1-2-3. Master/satellite system with external (remote) printer 1-2-4. The system with LAN printer 	I-6 I-7
2.	2. System down and recovery	I-9
	2-1.Measures to prevent trouble	I-10
	2-2.Master terminal failure	I-11
	2-2-1. Check tracking master terminal failure	I-11 I-12 I-13 I-13
	2-3-1. Master/backup master down detection	I-14
	2-5.Satellite terminal down	I-14
	2-6.LAN printer down	I-15

To prevent malfunctions caused by the weak batteries, charge the memory protection batteries for over 8-hours.

- Before installation, initialize the terminal and leave it power on over 8-hours.
- After a longtime vacation(over 30 days), initialize the terminal and restore the program data if the terminal is in malfunction, and <u>leave it power on over 8-hours</u>.
- QT-6600 consumes batteries for saving data <u>during 6 minutes after turning off the terminal</u>.
- <u>Do NOT power off the terminal over 3 times</u> while a short term. (Except INIT or FC operation) Otherwise, it makes weak batteries.

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net