
Installation manual



SuperBoard II



Contents

1	Equipment setup flowchart	1
2	Superboard II installation	2
2.1	Superboard II kit	2
2.2	Way to proceed	3
2.3	Installation of Dallas chip (optional)	6
2.4	To load IPL	6
2.5	To load program Flash EPROM	8
2.6	ECR updating from another ECR	10
2.7	Flash Eprom initialization	11
3	Inline system	12
3.1	Inline cable	12
3.2	ARCNET circuit	12
3.3	Inline connector	12
3.4	Warning light	12
4	Connectors RS232	13
4.1	PIN Layout on COM 4	13
4.2	PIN Layout on COM 5	13
4.3	PC connection COM 4 or 5	13
4.4	Other cable connection	14
5	To change Backup Battery	14
6	Superboard II programming flowchart	15
6.1	Superboard II setting up	15
6.2	Replacing or adding an inline terminal	16
6.3	Deleting a terminal	17
7	Advices	17
7.1	Message “SPB II server...”	17
7.2	Message “process error”	17

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)