

ELECTRONIC CASH REGISTER

TE-100

THANK YOU
YOUR RECEIPT
CALL AGAIN !

GROCERY
DAIRY
H. B. A.
FROZEN
FOOD
DELICATESSEN



Eu Di U.K.

USER'S MANUAL

CASIO®

Introduction & Contents

Introduction & Contents	4
Getting Started	7
Remove the cash register from its box.	7
Remove the tape holding parts of the cash register in place.	7
Install the three memory backup batteries.	7
Install receipt/journal paper.	9
Plug the cash register into a wall outlet.	11
Insert the mode key marked "PGM" into the mode switch.	11
Turn the mode key to the "REG" position.	11
Set the date.	12
Set the time.	12
Select printouts receipt or journal.	12
Tax table programming	13
Introducing TE-100	17
General guide	17
Roll paper, Receipt On/Off key, Mode key, Drawer, Drawer lock	17
Mode switch, Lock/unlock the multipurpose tray	18
Displays	19
Keyboard	20
Basic Operations and Setups	22
How to read the printouts	22
How to use your cash register	23
Displaying the time and date	24
Preparing and using department keys	25
Registering department keys	25
Programming department keys	26
Registering department keys by programming data	27
Preparing and using PLUs	28
Programming PLUs	28
Registering PLUs	29
Preparing and using discounts	30
Programming discounts	30
Registering discounts	31
Preparing and using reductions	32
Programming for reductions	32
Registering reductions	33
Registering charge and check payments	34
Registering returned goods in the REG mode	35
Registering returned goods in the RF mode	36
Registering money received on account	37
Registering money paid out	37
Making corrections in a registration	38
No sale registration	40
Printing the daily sales reset report	41
Convenient Operations and Setups	42
Clerk control function	42
Clerk sign on and sign off	42
Post-finalization receipt format, General printing control, Compulsory, Machine features	43
About post-finalization receipt	43

Programming general printing control	44
Programming compulsory and clerk control function	45
Programming read/reset report printing control	46
Setting a store/machine number	46
Programming to clerk	47
Programming clerk number	47
Programming trainee status of clerk	47
Programming descriptors and messages	48
Programming report descriptor, grand total, special character, report title, receipt message and clerk name	48
Report descriptor	48
Clerk name, Grand total, Special character, Report title	49
Receipt message	50
Programming department key descriptor	50
Programming PLU descriptor	51
Programming function key descriptor	52
Programming receipt message/logo stamp control function	52
Entering characters	53
Using character keyboard	53
Entering characters by code	54
Department key feature programming	55
Batch feature programming	55
Individual feature programming	56
PLU feature programming	57
Batch feature programming	57
Individual feature programming	58
Printing VAT breakdowns	61
Percent key feature programming	62
Currency exchange programming	64
Currency exchange rate programming	64
Currency exchange feature programming	64
Other function key feature programming	67
Cash, Charge, Check key	67
Received on account, Payout key, Minus key	68
#/No sale key	68
Calculator functions	69
About the daylight saving time	70
Printing read/reset reports	71
Reading the cash register's program	77
Troubleshooting	80
When an error occurs	80
When the register does not operate at all	81
When the L sign appears on the display	82
In case of power failure	82
User Maintenance and Options	83
To replace journal paper	83
To replace receipt paper	84
Options	84
Specifications	85
Index	86

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)