## SERVICE MANUAL

(without price)

**ELECTRONIC CASH REGISTER** 

TE-2200/2400

(EX-443/544)

**AUG. 2005** 



**CASIO**®

## **CONTENTS**

TE-2200/2400	PAGE
1. SPECIFICATIONS	1
2. MACHINE INITIALIZATION	4
3. DISASSEMBLY	7
4. CIRCUIT EXPLANATION	17
5. DIAGNOSTIC OPERATION	29
6. ERROR CODE LIST	55
7. IC DATA	59
8. PCB LAYOUT	66
9. CIRCUIT DIAGRAMS	68
10. PARTS LIST	82

To prevent malfunctions caused by the weak batteries, charge the memory protection batteries for over 12-hours before installation or after a long-time vacation (over 30 days).

- Before installation, initialize the terminal and leave it turn on over 12-hours.
- After a long-time vacation, initialize the terminal and restore the program data if the terminal is in malfunction, and leave it turn on over 12-hours.
- Over 48-hours charging makes the batteries fully charged.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/casio/TE-2200 and TE-2400 service manual.htm

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM