

ELECTRONIC CASH REGISTER TE-2200

User's Manual

Introduction

Setting Up

Getting Started

Paper Installation

Set Date/time

Introducing the Terminal

Display/Keyboard

Sheet Holder

Basic Operations & Setups

Registrations

Programs

Advanced Operations

Useful Features

Reports

Troubleshooting

Error Code Table

User Maintenance

Paper Replacement



Introduction & Contents

Introduction & Contents	2
Getting Started	10
Remove the cash register from its box.....	10
Remove the tape holding parts of the cash register in place.....	10
Install receipt/journal paper.....	11
Plug the cash register into a wall outlet.....	14
Insert the mode key into the mode switch.....	14
Turn the mode key to the "REG" position.....	14
Set the date.....	15
Set the time.....	15
Tax table programming	16
Introducing TE-2200	20
General guide	20
Display	24
Keyboard	26
Allocatable functions	28
Basic Operations and Setups	30
How to read the printouts	30
How to use your cash register	31
Assigning a clerk	32
Clerk button	32
Clerk secret number key	32
Displaying the time and date	33
To display and clear the date/time	33
Preparing coins for change	33
Preparing and using department keys	34
Registering department keys	34
Programming department keys	35
To program a unit price for each department	35
To program the tax calculation status for each department	35
To program high amount limit for each department	36
Registering department keys by programming data	37
Preset price	37
Preset tax status	37
Locking out high amount limitation	37
Preparing and using PLUs	38
Programming PLUs	38
To program a unit price for each PLU	38
To program tax calculation status for each PLU	38
Registering PLUs	39
Preparing and using discounts	41
Programming discounts	41
Registering discounts	41
Discount for items and subtotals	41
Registering reductions	42
Reduction for items	42
Preparing and using reductions	42
Programming for reductions	42
To program preset reduction amount	42
Reduction for subtotal	43
Registering credit and check payments	44
Check	44
Charge	44
Mixed tender (cash, charge and check)	44

Registering both the Euro and local currency	45
Registering returned goods in the REG mode	47
Registering returned goods in the RF mode	47
Normal refund transaction	47
Reduction of amounts paid on refund	48
Registering money received on account	48
Registering money paid out	48
Making corrections in a registration	49
To correct an item you input but not yet registered	49
To correct an item you input and registered	50
To cancel all items in a transaction	51
No sale registration	51
Printing the daily sales reset report	52
Advanced Operations	54
Stock check	54
Clerk interrupt function	54
Single item cash sales	55
Addition	56
Addition (plus)	56
Premium (%+)	57
Tray total	58
Tray total premium/discount	58
Multiple item totalling function	58
Coupon transactions	59
Coupon registration using <COUPON> (coupon key)	59
Coupon registration using <COUPON2> (coupon 2 key)	59
Preset tender amount	60
Registering loan amounts	60
Registering pick up amounts	61
Changing media in drawer	61
Bottle link operation	62
Bottle returns	62
Bottle return key	62
Arrangement key registrations	63
Set menu	63
Currency exchange function	64
Registering foreign currency	64
Full amount tender in foreign currency	64
Partial tender in a foreign currency	65
Tips	66
Inputting the number of customers	67
Temporarily releasing compulsion	68
Text recall	68
Printing slip	69
Printing slips	69
To perform auto batch printing 1	70
To perform auto batch printing 2	70
About the maximum number of slip lines	70
Check tracking systems	70
Check tracking system	70
Opening a check	71
Adding to a check	71
Issuing a guest receipt	72
Closing a check memory	72

Introduction & Contents

New/old check key operation	73
Add check	74
Separate check	75
Price reductions (red price)	76
Condiment/preparation PLUs	77
VAT breakdown printing	78
Deposit registrations	79
Deposit from customer	79
Deposit from customer during sales transaction	79
Bill copy	80
Actual stock quantity inquiry	81
Unit price inquiry	81
Previous item void using <review>	82
Scanning PLU	83
Item registration	83
By scanner/code input/one touch NLU key	83
Not found PLU	83
Programming to clerk	84
Programming clerk number	84
Programming trainee status	84
Programming commission rate	84
Programming descriptors and messages	85
Programming receipt message, machine No. and clerk name	85
Programming department/transaction key descriptor	87
Entering characters	89
Using character keyboard	89
Entering characters by code	90
Character code list	90
Editing characters	91
Correcting a character just entered	91
Correcting and adding a PLU descriptor already set	91
Correcting a key descriptor already set	91
Correcting a message descriptor already set	91
Printing read/reset reports	92
To print the individual department, PLU read report	92
To print the financial read report	93
To print the individual clerk read/reset report	93
To print the daily sales read/reset report	94
To print the PLU read/reset report	96
To print the hourly sales read/reset report	96
To print the monthly sales read/reset report	97
To print the group read/reset report	97
To print the periodic 1/2 sales read/reset reports	98
To print other sales read/reset reports	100
Reading the cash register's program	101
To print unit price/rate program (except PLU/scanning PLU)	101
To print key descriptor, name, message program (except PLU)	102
To print the PLU program	103
Troubleshooting	104
When an error occurs	104
Clearing a machine lock up	106
When the register does not operate at all	106
In case of power failure	107

User Maintenance and Options	108
To replace journal paper	108
To replace receipt paper	109
Options	109
Specifications	110
Index	111

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/casio/TE-2200 users EU ver manual.html>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)