

SERVICE MANUAL

(without price)

ELECTRONIC CASH REGISTER

TE-3000S/4000F/4500F

(EX-466/566/567)

JULY. 2003



TE-3000S



TE-4000F



TE-4500F

CASIO®

CONTENTS

TE-3000S/4000F/4500F	PAGE
1. SPECIFICATIONS.....	1
2. CONNECTOR LOCATIONS	4
3. MACHINE INITIALIZATION	5
4. DISASSEMBLY	8
5. CIRCUIT EXPLANATION	15
6. OPTION INSTALLATION.....	27
7. IN LINE	29
8. ON LINE	32
9. DIAGNOSTIC OPERATION	34
10. ERROR CODE LIST	55
11. IC DATA	59
12. PCB LAYOUT	69
13. CIRCUIT DIAGRAMS.....	72
14. PARTS LIST	92

To prevent malfunctions caused by the weak batteries, charge the memory protection batteries for over 12-hours before installation or after a long-time vacation (over 30 days).

- **Before installation, initialize the terminal and leave it turn on over 12-hours.**
- **After a long-time vacation, initialize the terminal and restore the program data if the terminal is in malfunction, and leave it turn on over 12-hours.**
- **Over 48-hours charging makes the batteries fully charged.**

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)