SERVICE MANUAL

(without price)

ELECTRONIC CASH REGISTER

TE-7000S/8000F/8500F

(EX-468/568/569)

FEB. 2003



TE-8000F

TE-8500F

CASIO_®

CONTENTS

TE-7000S/8000F/8500F		PAGE
1.	SPECIFICATIONS	1
2.	CONNECTOR LOCATIONS	4
3.	MACHINE INITIALIZATION	5
4.	DISASSEMBLY	9
5.	CIRCUIT EXPLANATION	17
6.	OPTION INSTALLATION	34
7.	IN LINE	36
8.	ON LINE	39
9.	DIAGNOSTIC OPERATION	41
10.	ERROR CODE LIST	65
11.	IC DATA	70
12.	PCB LAYOUT	76
13.	CIRCUIT DIAGRAMS	80
14.	PARTS LIST	103

To prevent malfunctions caused by the weak batteries, charge the memory protection batteries for over 12-hours before installation or after a long-time vacation (over 30 days).

- Before installation, initialize the terminal and leave it turn on over 12-hours.
- After a long-time vacation, initialize the terminal and restore the program data if the terminal is in malfunction, and leave it turn on over 12-hours.
- Over 48-hours charging makes the batteries fully charged.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/casio/TE-7000S and TE-8000F service manual.h

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM