SERVICE MANUAL

(without price)

ELECTRONIC CASH REGISTER

TK-7000 (EX-575B*)

FEB. 2000



Printer Model : M-U420-071

INDEX

CASIO

CONTENTS

TK-7000 Page

1. SPECIFICATIONS 1
2. INITIALIZE (MAC) OPERATION 4
3. F-INIT (FMAC) OPERATION 4
4. BLOCK DIAGRAM 5
5. TO OPEN THE UPPER CASE 7
6. CIRCUIT EXPLANATION 9
   - 6-1. Power supply circuit 9
   - 6-2. Reset and power down circuit 10
   - 6-3. CPU description 11
   - 6-4. Momory chip selection circuit 13
   - 6-5. Flash ROM1 address circuit 14
   - 6-6. Flash ROM2 circuit 14
   - 6-7. Flash Pack circuit (Memory Cassette RAC-9) 15
   - 6-8. Memory map 16
   - 6-9. Printer drive circuit 17
   - 6-10. RS232C port COM1 circuit 17
   - 6-11. RS232C port COM2 and COM3 circuit 18
   - 6-12. Keyboard selection switch 19
   - 6-13. To mount optional circuit 19
     - 1) Clerk key circuit 19
     - 2) Multi-drawer circuit 21
     - 3) Paper near end sensor circuit 22
   - 6-14. Display controller uPD78015FGC526-AB8 23
   - 6-15. Segment display driver uPD16312GB-3B4 24
   - 6-16. DC/DC convertor circuit 25
   - 6-17. ARCNET circuit (IO-PB14) 25
7. DIAGNOSTIC OPERATION 31
   - 7-1. To start the diagnostic program 31
   - 7-2. Check item 31
   - 7-3. Operation of each test 31
   - 7-4. Switch status test 32
   - 7-5. Individual function test 33
   - 7-6. To exit the diagnostic mode 49
8. ERROR CODE LIST 50
9. IC DATA 53
10. PCB LAYOUT 67
11. CIRCUIT DIAGRAM 69
12. PARTS LIST 93

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/cashregisters/Casio_TK-7000_service_manual.html

Checkout our free online Keysheet Maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

THE-CHECKOUT-TECH.COM