

# Dealer's Manual

## (for TE-900, TE-1500, TK-950, TK-1550: version2.40)

<b>Initialization (for TE-900/TE-1500).....</b>	<b>3</b>
Initializing the cash register .....	3
Automatic initialization.....	3
Manual initialization.....	3
Clearing a machine lock up .....	3
<b>Initialization (for TK-950/TK-1550) .....</b>	<b>4</b>
Initializing the cash register .....	4
Automatic initialization.....	4
Manual initialization.....	4
Clearing a machine lock up .....	4
<b>RAC-12B .....</b>	<b>5</b>
Usage of RAC-12B .....	5
Preparation for using the RAC-12B (formatting RAC-12B) .....	5
How to backup the programming data to the RAC-12B .....	5
How to restore the programming data from the RAC-12B .....	5
Error code .....	5
<b>Scanning PLU .....</b>	<b>6</b>
Summary.....	6
Preparation .....	6
Registration.....	7
Not found PLU .....	7
Unreadable barcode .....	8
Programming.....	8
To allocate <OBR> key .....	8
To modify unit price and linked department / add new scanning PLU item .....	8
Report .....	9
To issue individual scanning PLU item report.....	9
To issue individual scanning PLU item report.....	9
To reset all scanning PLU item sales data.....	9
Advanced operation for scanning PLU.....	10
To print/not print scanning code, to set inactive days .....	10
To issue inactive scanning PLU report .....	10
<b>Parameter sheet.....</b>	<b>11</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net