


NCR 5964 12.1-inch Touch LCD

Release 1.0

User's Guide



B005-0000-1324

Issue B

Table of Contents

Chapter 1: Overview

| | |
|---|-----|
| Introduction | 1-1 |
| Model Number | 1-2 |
| Major Model Code | 1-2 |
| Sub Model Code | 1-2 |
| Power Code..... | 1-2 |
| Language Code..... | 1-2 |
| Compatibility | 1-3 |
| Standard Features | 1-3 |
| Wedge Controller | 1-4 |
| Speaker..... | 1-4 |
| External Standard PC Keyboard Connector | 1-4 |
| Optional Features..... | 1-5 |
| 2-Track JIS MSR | 1-5 |
| No MSR Kit | 1-5 |
| Peripheral Tray Mount for 5964 | 1-5 |
| Weights and Measures Label Kit..... | 1-5 |
| Integrated 2 x 20 Customer Display | 1-6 |

Chapter 2: Site Preparation

| | |
|-------------------------------------|-----|
| Physical Environment | 2-1 |
| Operating Range..... | 2-1 |
| Storage Range | 2-1 |
| Transit Range | 2-1 |
| Electrical Environment..... | 2-2 |
| Power Consumption (Touch Head)..... | 2-2 |
| Dimensions | 2-3 |
| Tilt/Swivel Dimensions | 2-3 |

| | |
|------------------------------------|-----|
| 5964 w/ Customer Display | 2-4 |
| 12.1-inch LCD Display | 2-5 |
| LCD Panel..... | 2-5 |
| LCD Adapter Board | 2-5 |
| LCD Backlight Inverter Module..... | 2-6 |

Chapter 3: Installation

| | |
|---|------|
| Installing the 5964 | 3-1 |
| Serial Number Location..... | 3-2 |
| Connector Panel Access..... | 3-2 |
| Connector Panel Location..... | 3-3 |
| 5964 Cables Connecting to a POS | 3-3 |
| Cable Routing | 3-4 |
| Mounting Options | 3-4 |
| Installing an Integrated Customer Display (5972-F040) | 3-5 |
| Powering Up..... | 3-10 |
| Calibrating the Touch Screen | 3-11 |
| Calibration Using MicroTouch (Windows) | 3-11 |
| Calibration Using Microcal (DOS) | 3-14 |
| Summary | 3-15 |
| Screen Saving Feature | 3-16 |

Chapter 4: Programming

| | |
|---------------------------------------|-----|
| Device Interfaces | 4-1 |
| 12.1-Inch DynaKey Video Drivers | 4-1 |
| Wedge Controller Interface..... | 4-2 |
| Touch Screen Interface..... | 4-2 |
| MSR Interface..... | 4-4 |
| PS/2 Keyboard Interface | 4-4 |
| Panel OFF/ON Sequence..... | 4-4 |

Chapter 5: Service and Repair

| | |
|--|------|
| Problem Isolation Procedures | 5-2 |
| Servicing the Touch Screen Module | 5-5 |
| Touch Screen Cleaning Procedures | 5-5 |
| MSR Cleaning Cards | 5-5 |
| Disassembly Procedures | 5-6 |
| Removing the Back Cover | 5-6 |
| Removing the 5964 Wedge Touch Controller Board | 5-9 |
| Removing the LCD | 5-11 |
| Replacing the Backlight | 5-12 |
| Replacing the Touchscreen | 5-13 |
| Removing the MSR | 5-14 |
| Spare Parts List | 5-15 |
| External Keyboard Connector | 5-16 |

Index

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*