olivetti



Instructions Instructions d'emploi Bedienungsanleitung Instrucciones de uso









506522R

Olivetti Lexikon, S.p.A. Divisione Home/Office 77, Via Jervis - 10015 Ivrea (Italy)

Copyright © 2001, by Olivetti

All rights reserved



The **CC** mark affixed to the product certifies that the product satisfies the basic quality requirements.



Your attention is drawn to the following actions that could compromise the characteristics of the product:

- · incorrect electrical supply;
- incorrect installation; incorrect or improper use, or, in any case, not in accordance with the warnings given in the User Manual supplied with the product;
- replacement of original components or accessories with others of a type not approved by the manufacturer, or carried out by unauthorized personnel.

WARNING: THIS EQUIPMENT MUST BE EARTHED.
ATTENTION: CETTE UNITE DOIT ETRE CONNECTEE A LA TERRE.
ACHTUNG: DIESES GERÄT MUSS EINEN ERDUNGSANSCHLUSS HABEN.
ATENCION: ESTE EQUIPO DEBE ESTAR CONECTADO A UNA TOMA DI TIERRA.
APPARATET MÅ KUNTILKOPLES JORDET STIKKONTACT.
APPARATEN SKALL ANSLUTAS TILL JORDAT NÄTUKKAT.
LAITE ON LITTETTÄVÄ SUKO-RASIAAN.
Lederen med grøn/gul isolation ma kun tilsluttes en klemme maerkrt eller

To disconnect the cash register from the line voltage, unplug its power cord from the power outlet. The power outlet must be located on a wall, near the cash register and easily accessible.

Preface

The electronic cash register described in this manual is designed to help your business function smoothly by providing efficient register operations and accurate management reports. Start-up is quick and easy, yet there are many options that can be added and revised so that you can customize your operations for optimum productivity. Here are just a few of the cash register's many valuable features:

- 12 departments;
- 99 or 200 Price Look-Up (PLU) settings, depending on the model purchased;
- 6 clerk numbers to monitor the sales of individual employees;
- possibility of assigning a three-digit security code that prevents unauthorized access to individual clerk transactions (during register mode only);
- possibility of defining a password that prevents unauthorized access to the machine's programming mode (PRG) and Z management report mode;
- possibility of defining a password that prevents unauthorized access to the cash register's calculator mode;
- printer with journal record and receipt printing capabilities;

- possibility of programming the departments with a tax status, single/multiple item sale and a preset price;
- possibility of activating a non-print mode for times when a sales receipt is not required yet you still need to keep track of sales totals;
- possibility of using the cash register's calculator mode which provides the convenience of a calculator when a quick calculation is needed;
- Euro exchange rate programming;
- possibility of programming the machine to work with one of two base currencies, Local or Euro, so that cash register computes in the currency set and automatically converts the related transaction totals into the other currency;
- a rear customer display and front operator display each consisting of a 9-character transaction and message line, or just a 9-character front operator display, depending on the model purchased;
- · automatic tax computations for 4 different VAT rates;
- department-linked entry options that streamline and speed-up operation;
- periodic management and financial reports which provide up-to-date sales analysis;
- battery back-up protection for the records and programming data.

GETTING ACQUAINTED WITH YOUR CASH REGISTER 1 Standard Accessories 2 Using this Manual 2 Unpacking and Setting Up the Cash Register 3 Maintaining the Cash Register 3 THE KEYPAD 4 Keypad Functions...... 5 THE CONTROL SYSTEM 6 The Control Switch 6 Removable Cash Drawer with Lock 6 Operator and Customer Displays 7 Special Symbol Indicators 7 Time Display 7 ERROR CONDITIONS 8 The Error Alarm 8 Clearing an Error 8

Table of Contents

BACK-UP BATTERY SYSTEM	9
nserting/Replacing Batteries	9
PRINTER COMPARTMENT	. 10
The Ink Roller	11
nstalling the Ink Roller	
Paper Tape	
Loading Paper	. 12
QUICK START	. 13
Programming the Euro as the Cash Register's	
Base Currency	. 14
Helpful Hints for a Successful Start-Up	
CASH REGISTER PROGRAMMING	. 14
Setting Cash Register Features	. 14
Making Changes to Cash Register Programming	
Entering the Program Mode	. 15
Exiting the Program Mode	. 15
Clearing Errors	
Clerk Numbers and Secret Codes	
Date and Time	
Percent Discount (-%)	
Decimal Point Position	
/alue Added Tax (VAT) Rates	18
Department Tax Status Price Look-Ups (PLUs)	. 18

Euro Exchange Rate Programming	21
Programming System Options	
PLU Programming Dump Report	22
Programming a Manager Password	
Using the Cash Register in a Password Protected	
Mode	24
Calculator Mode	24
The Non-Print Mode	25
Machine Programming Report	
TRANSACTION EXAMPLES	26
Entering the Register Mode	26
Exiting the Register Mode	26
Clearing Errors	
Transaction Symbols	
Sample Receipt	27
Standard Transactions in Local Base Currency	
Examples of Transactions in Euro Base Currency	36
Minus (-) Key Transactions	40
Percent Discount (-%) Transactions	42
PLU Codes	46
Voids and Refunds	48
Other Transactions	50

MANAGEMENT REPORTS	52
X Position Report	52
Z Position Report	52
Clerk Report	52
All PLU Report	53
X and Z Financial Report	
Balancing Formulas	55
APPENDIX	56
Totalizers and Counters Table	56
Cash Register Specifications and Safety	57

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/olivetti/ECR-2150 and ECR-2250 instruction programmed in the programmed in the contraction of the contractio

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM