

# OLYMPIA

**CM1930  
EURO FUNCTION  
AND  
TRIANGULATION**



# EURO AND FCE FOREIGN CURRENCY EXCHANGE

This system has been designed to manage (by flag switching) the following currency exchange functions,

- A) Standard FCE Functions.
- B) EURO during 01/01/99 to 31/12/2001 Including TRIANGULATION CALCULATIONS.
- C) Other country exchange rates against the EURO
- D) EURO during 01/01/2002 to 30/06/2002
- E) Revert to FCE after 01/07/2002

This is the key that will guide you and give ease of use of the Euro.



FCE1 = Eurocard  
FCE2 = Eurocheck  
FCE3 = Euro Table  
FCE 4-15 = Foreign Currency

During the transitional period, FCE01 and FCE02 may be used only for Eurocheck or Eurocard.



FCE1 = Eurocard  
FCE2 = Eurocheck

FCE 03 may only be used for generating the Euro Exchange Table and the Triangulation Exchange Table.

When Flag 31 is set to 0100 the Eurotable will print even if there is not an Euro Transaction.

The following Flags must be set as follows:

```
PROG SYSFLAG  
32 FCE RCT1 00
```

FLAG 32 must be set to 00

```
PROG SYSFLAG  
33 FCE PNT 0100
```

FLAG 33 must be set to 0100

FCE 04 to FCE 15 are the 12 different Foreign Currency Exchange Tables which are preset with their exchange rate against the Euro.



FCE 4-15 = Foreign  
Currency

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*