



PROGRAMMING INSTRUCTION

ECR 579 Flash

Table of contents:

	Page
1. Basic Feature	3
2. System RESET, initialisation machine	6
3. Key description, Default key layout	7
4. S – Mode, Service Mode Operation	9
4.1 Machine establishment dump (Initialize basic system)	9
4.2 System building dump – Memory set, Training	10
4.3 Keyboard program mode	11
4.4 Print out establishment S - Mode	13
5. PRG – Mode, Program Mode Operation	14
5.1 Program Department	15
5.2 Program Department group name	16
5.3 Program PLU	17
5.4 Program Link PLU	18
5.5 Program PLU group name	19
5.6 Program Clerk	20
5.7 Program Cashier	22
5.8 Program Tender media	22
5.9 Program Key (+, -)	23
5.10 Program Key (+%, -%)	24
5.11 Program Manager pass code	24
5.12 Program Machine number	25
5.13 Program P-register (Machine option)	25
5.14 Program Date	28
5.15 Program Time	29
5.16 Program Currency – FC	29
5.17 Program P-register (Report print item)	30
5.18 Program P-register (Double height line)	31
5.20 Program PLU assign - „PLU Clerk Report“	32
5.22 Program Com port machine	32
5.23 Programming the machine text	33
5.24 Program TAX	33
5.25 Program Logo message	34
5.26 Program AD message	34
5.33 Print out program dump report PRG-Mode	34
5.34 Stock-PLU,Link-PLU Stock counter adjustment	35
8. Management Reports. X-Report.Z-Report	36
9. Character Table. Alphabet Key Layout for Caption	38
10. Error message (error symbols)	40
11. Plug-in peripherals	42
12. Instructions for MANAGER / HELPER	43
14. Flash-Program	44
16. Connection Scanner	45

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*