

## OMRON AFGREIÐSLUKASSI

### LEIÐBEININGAR OMRON CT3107

#### LYKILSSTÖÐUR

REG	Vinnslustaða
X	Aflestur án hreinsunar
Z	Lokaaflestur—hreinsun
P	Forritun
Lock	Kassi læstur

Tími og dagsetningabreytingar eru sjálfvirkar. Þær þarf aðeins að framkvæma ef rafhlöður ónýtast og/eða rafstraumur fer af afgreiðslukassa samtímis.

#### DAGSETNINGU BREYTT

Lykill settur í X stöðu  
Dagsetning stimpluð inn ár-mán-dag. (04 05 14) 14. maí 2004.  
Stutt á X/Time

#### KLUKKU BREYTT

Lykill settur í X stöðu  
Tími settu inn t.d. 13 30  
Stutt á X/Time

#### SALA-GEFIÐ TIL BAKA

Lykill í REG stöðu  
KR upphæð skráð inn  
Stutt á vöruflokkahnapp  
Sutt á samtals hnapp  
Móttækin upphæð skráð inn í kassa og stutt á GREITT

#### MARGFÖLDUN(seldar fleiri en ein eining)

Lykill í REG stöðu  
Skráð inn einingarfjöldi seldrar vöru  
Stutt á margföldunartakkann X/Time  
Skráð inn einingarverð vörunnar á vöruflokk  
Samtals söluupphæð fengin með að styðja á hnapp SAMTALS  
Stutt á GREITT

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/omron/CT-3107 handbook ICELANDIC manual.h](https://the-checkout-tech.com/manuals/omron/CT-3107%20handbook%20ICELANDIC%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)