

OMRON AFGREIÐSLUKASSI LEIÐBEININGAR OMRON RSS X2 THERMAL Elektrónísk Sjóðsvél



Búið að setja inn dagsetningu og tíma. Tími og dagsetningabreytingar eru sjálfvirkar..

Kveikt er á RSS-X2 kassanum með rofa á hægri hlið aftarlega að neðan.

Þá kemur upp í glugga “Næsti kúnni” og er þá kassinn tilbúin til notkunnar.

Ef “Næsti Kúnni” kemur ekki upp í glugga þarf að athuga eftirfarandi. Ýtið á CLR nokkrum sinnum og síðan á takkan sem heitir LYKILSTAÐA nokkru sinnum þar til þar stendur SÖLU STAÐA. Ýtið þá á GREITT og kemur þá upp 0 og er kassinn þá tilbúinn.

Forritun á X2 kassanum fer fram með að ýta á takkann “LYKILSTAÐA”, og síðan á GREITT og einnig eru pílurnar á PUNKTA takkanum og 00 takkanum notaðar til að fara á milli forrita.

ATHUGIÐ: EF Á AÐ FORRITA EITTHVAÐ Í KASSANUM ÞARF FYRST AÐ TAKA UPPGJÖR Í Z1 UPPGJÖRI TIL AÐ FORRITUN VIRKI.

ATHUGIÐ AÐ EF Á GLUGGA KEMUR “ERROR 145 EÐA 146” ÞÁ VANTAR PAPPÍ Í KASSA.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/omron/RSS-X2 handbook ICELANDIC manual.htm](https://the-checkout-tech.com/manuals/omron/RSS-X2%20handbook%20ICELANDIC%20manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)