

MANUAL
VECTRON COMMANDER
PAGE 1/1

Release Dec 20 2000

Dear Customer,

Your purchase of VECTRON COMMANDER 6 gives you a powerful program to maintain your Vectron POS system and provide the information you need to run your business.

With VECTRON COMMANDER 6 you may connect up to 1,000 POS Terminals and have full control over essential programming such as PLUs and Prices from your Head Office. Sales Data can be polled automatically, or on-demand so you can stay on top of any hot spots. This polled data can be formulated to provide the reports you need. The terminals can be polled on-line or by modem or ISDN. Administer all your worldwide terminals from your Headquarters.

I Basics

I.1 Structure of this manual

I.1.1 Structure

This Manual has 3 parts. Part 1 covers installation, connecting COMMANDER with the terminals, and the basic concepts of operating the software. Part 2 explains each Function in detail. Part 3 are supplements with additional information for external Help programs and connection of terminals.

I.1.2. Conventions

'*README.TXT*' a Folder or Filename.

'*SETTINGS*' a Menu item

'<INSERT>' a key or a button

1.2 Latest information

The information contained in this manual is the latest that was available at the time of printing. As Commander is constantly being improved, the latest information will be in the '*VC_READM.HTM*' or '*VC_READM.TXT*' and '*VCCHANGE.TXT*' files, which are automatically installed with VECTRON COMMANDER 6.

1.3. Backing up your data

COMMANDER 6 is saving your very important data on your hard drive. A failure of this drive could cause immense economic damage. Therefore you should save your data from time to time. Some of the options are floppy disks, CD-ROM or tapes. Your PC vendor can suggest the method that is best for you. All the files in the VECTRON\VCOM6\DATA folder should be backed up regularly.

2 Installation of COMMANDER 6

If your dealer has installed COMMANDER 6 for you, please continue with CHAPTER 3.

2.1 Installation of Hardlock (Dongle)

Before you will install COMMANDER 6, you should install the Hardlock (Dongle), which is included with your software. Remove the printer cable from the parallel port of your computer. With the end marked 'parallel' facing the computer, screw the Hardlock to the parallel port. Connect the printer cable with the free end of the Hardlock.

Install the Hardlock driver. You will find this driver on the CD-ROM in the `\DRIVERS` folder. If a printer is connected to the Hardlock, it should be switched ON when starting Commander.

2.2 Installation of VECTRON COMMANDER 6

- **Insert the CD in your CD ROM Drive**
- **Double click on MY COMPUTER and then click the CD ROM drive**
- **Change to folder `\PROD\VCOM6`**
- **Double click the file `VCOM6-6XXX-YYY.EXE`**
- Where X XX= the current release and YYY = the language desired

The installation program will start. If VECTRON COMMANDER 6 is already installed, you will see a window labeled 'Vectron Commander 6 Maintenance'. In this case please continue with Chapter 2.2.2.

2.2.1 New installation

If this is a new installation you will see a number of windows:

WELCOME
Click <NEXT> to continue

INFORMATION
Please take a moment to read the information on this page as there will be important release and installation notes that are not yet in the manual

DESTINATION LOCATION
Here you will define the Folder for installation. `C:\VECTRON\VCOM6` should be changed only in exceptional cases.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/PC Software/Vectron Commander v6 user manu](https://the-checkout-tech.com/manuals/PC%20Software/Vectron%20Commander%20v6%20user%20manual/)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://the-checkout-tech.com)