



**Panasonic® 5000 Series  
Version MR4.0  
Programming Instructions**

Revision 1.0, July 1998  
©1998 by Matsushita Communication Industrial Co. LTD.  
All rights reserved. Published 1998.  
Printed in the United States of America

—  
This original manual is printed on recycled paper,  
consisting of 50% recycled and  
10% post consumer waste.

## Table of Contents

FCC Warning .....	iv
Acknowledgements .....	v
Disclaimer .....	vi
Recycling Notice .....	vii
Using this Manual .....	viii
System Overview .....	1-1
Specifications .....	1-1
Keylock .....	1-2
Default Keyboard .....	1-3
Procedure List .....	1-4
Programming .....	2-1
Overview .....	2-1
Keyboard Programming .....	2-3
Key Codes .....	2-5
Key Code Definitions .....	2-10
Memory Configuration .....	2-16
Memory Allocation .....	2-24
Memory Conversion Chart .....	2-24
P21 Report Total Arrangement .....	2-27
P23 Tax Configuration .....	2-41
P24 System Flags .....	2-45
P24 Miscellaneous Flags .....	2-62
P24 Tandem & Macro Commands .....	2-87
P24 Time-Activated Macros .....	2-92
P25 System Descriptors .....	2-93
P26 Time Ranges .....	2-102
P28 Product Mix Groups .....	2-107
P30 Prompts & Error Messages .....	2-109
P31 Cashier File .....	2-118
P32 Server File .....	2-120
P34 Groups .....	2-122

P27 PLU Additions & Deletions	2-124
P35 PLU File	2-126
P36 Coupons	2-132
P37 Negative File	2-134
P38 Guest Check/Customer File	2-136
P39 Tare Weight	2-138
P51 KPS Standard Menu	2-140
P53 Employee File	2-142
P54 Ingredient File	2-144
P55 Recipe File	2-146
P56 Pay Rates	2-148
P57 Kitchen Video System	2-150
Monochrome KVS Modes	2-150
Color KVS Modes	2-151
KVS Descriptors	2-152
Screen Colors	2-152
P33 Date & Time	2-158
System Set-Up	3-1
Flash ROM	3-2
Flash ROM (U35 CPU Board)	3-3
Download	3-5
Clearing Flash ROM	3-9
Memory Configuration	3-11
Workstation Status	3-11
In-line ID Settings	3-11
P21 RAM Clear	3-13
P20 Self-Diagnostics	3-16
Hard Key Locations	3-20
Keyboard Printout Matrix	3-21
Cable Pin-Outs	3-22
Channel 1 (CH1) Pin-Outs	3-22
Channel 2 (CH2) Pin-Outs	3-25
Channel 3 (CH3) Pin-Outs	3-27
Entering the Program	4-1
Suggested Programming Order	4-1
P2 Mode Sequence Overview	4-2
Data Entry Procedures	4-3
Data Entry Abbreviations	4-4
Descriptor Entries	4-5

Descriptor Codes .....	4-5
Alpha Keyboard Layout .....	4-6
Program Exit .....	4-7
X1 Mode Programs .....	4-8
Starting Order Number .....	4-9
Remote Steering .....	4-10
Drawer Assignment .....	4-15
Server Disable .....	4-16
Starting Guest Check Number .....	4-17
P50 Program Printouts .....	4-18
P60 Downline Programming .....	4-19
Downlining to Programmed Workstations .....	4-19
Downlining to Unprogrammed Workstations .....	4-20
Downlining to an Individual Workstation .....	4-21
Downlining the PLU File .....	4-22
Index .....	5-1

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/panasonic/JS-500WS 5000 Series programming](https://the-checkout-tech.com/manuals/panasonic/JS-500WS%205000%20Series%20programming)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)