



**Panasonic® 7500 Series
Version 4.0
Programming Instructions**



Revision 1.0, December 1997
©1997 by Matsushita Communication Industrial Co. LTD.
All rights reserved. Published 1997.
Printed in the United States of America

This original manual is printed on recycled paper,
consisting of 50% recycled and
10% post consumer waste.

PG750QS4

Table of Contents

FCC Warning	iv
Disclaimer	v
Recycling Notice	vi
System Features	1-1
Specifications	1-1
Feature Summary	1-1
Keylock Positions	1-8
Procedure List	1-9
System Set-up	2-1
Overview	2-1
Dip Switch 1 (SW1)	2-1
Dip Switch 2 (SW2)	2-2
Jumpers 1-9 (JP1-JP9)	2-2
EPROM Configuration	2-3
Flash ROM Configuration	2-6
Memory Configuration	2-9
Printer Mode	2-9
In-line ID Settings	2-10
Kitchen Printers	2-10
Remote & Kitchen Printers	2-10
Kitchen Video System	2-11
Personal Computer	2-11
Initial Program Mode	2-12
Overview	2-12
Flash ROM Clear	2-13
Flash ROM Download	2-15
Flash ROM Downline	2-17
Boot ROM Test	2-26
P3 Special Menu	2-27
Overview	2-27
RAM Clear without Test	2-28
RAM Clear with Test	2-30
P21 RAM Clear	2-32
RAM Clear without Test	2-33
RAM Clear with Test	2-33
Z Counter/Non-Resettable Net Total Reset	2-35

TABLE OF CONTENTS

EJ Buffer Reset	2-35
Polling Buffer Reset	2-36
Product Projection Clear	2-36
P20 Self-Diagnostics	2-37
P22 Default Program Load	2-42
Default Keyboard Layout	2-44
Hard Key Codes	2-45
Hard Key Locations	2-46
Programming	3-1
Overview	3-1
Memory Structure	3-2
Keyboard Programming	3-3
Key Code Definitions	3-11
Memory Configuration	3-20
P21 Memory Allocation	3-26
Memory Conversion Chart	3-26
P21 Report Total Arrangement	3-28
P21 DCR Report Total Arrangement	3-36
P21 Calculation Totals	3-38
P23 Tax Configuration	3-41
P24 System Flags	3-45
P24 Miscellaneous Flags	3-60
P24 Tandem & Macro Commands	3-87
P24 Time-Activated Macros	3-94
P25 System Descriptors	3-96
P26 Time Ranges	3-108
P28 Product Mix Groups	3-114
P30 Prompts & Error Messages	3-116
P31 Cashier File	3-130
P32 Coupons	3-132
P34 Groups	3-138
P27 PLU Additions & Deletions	3-140
P35 PLU File	3-142
P36 Manager File	3-148
P39 Tare Weight	3-150
P40 86-Items	3-152
P42 Discounts & Surcharges	3-154
P51 KPS Standard Menu	3-156
P59-1 Employee File	3-158
P59-2 Pay Rates	3-160
P59-3 Grace Periods	3-162
P59-4 Ingredient File	3-164

P59-5 Recipe File	3-166
P59-6 KVS Programs	3-168
Monochrome KVS Modes	3-168
Color KVS Modes	3-169
KVS Descriptors	3-170
Screen Colors	3-170
Entering the Program	4-1
Overview	4-1
Descriptor Codes	4-4
Alpha Keyboard Layout	4-5
X1 Mode Programs	4-10
Workstation Mode	4-11
Starting Order Number	4-12
PLU Shift Level	4-13
Remote Steering	4-14
JS800RM Dip Switch Settings	4-18
Kitchen Printers	4-18
Remote & Kitchen Printers	4-18
Thermal Printer Dip Switch Settings	4-19
Cashier Disable	4-21
P33 Date & Time	4-22
P71 PLU Copy	4-23
P50 Program Printouts	4-24
P60 Downline Programming	4-25
Downlining to Programmed Workstations	4-25
Downlining to Unprogrammed Workstations	4-26
Downlining to an Individual Workstation	4-27
Downlining the PLU File	4-28
Appendix	5-1
PC/PF Loader	5-1
System Close & System Open	5-2
24-Hour Close	5-5
Deposit & Cash Report (DCR)	5-7
Phone Orders	5-9
Trace Mode	5-12
Cable Pin-Outs	5-18
Inventory Count Reset	5-26
Index	6-1
Worksheets	

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/panasonic/JS-750WS 7500 Series programming](https://the-checkout-tech.com/manuals/panasonic/JS-750WS%207500%20Series%20programming)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)