



ELECTRONIC CASH REGISTER

ER-2710,2715

SERVICE MANUAL

CONTENTS

EXPLANATION OF CIRCUITS	1
1. OVERVIEW	1
2. POWER MODULE CIRCUIT	1
3. RESET CIRCUIT	3
4. POWER FAILURE CIRCUIT	3
5. POWER ON/OFF TIMING CHART	4
6. KEYBOARD CIRCUIT	5
7. DISPLAY CIRCUIT	6
8. PRINTER CIRCUIT	7
9. DRAWER CIRCUIT	8
10. BUZZER CIRCUIT	8
11. BATTERY CIRCUIT	9
12. REAL TIME CLOCK(RTC) CIRCUIT	10
PARTS STANDARD	11
ASSEMBLY CONSTRUCTION & PARTS LIST	23
APPENDIX	28
A) BLOCK DIAGRAM	28
B) WIRING DIAGRAM	29
C) PARTS LAYOUT ON MAIN P.C.B	30
D) CIRCUIT DIAGRAM	31
E) PRINTER TIMING CHART	32
F) PRINTER ASSEMBLY/DISASSEMBLY DIAGRAM	33

NOTE: All specifications are subject to change without prior notice.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/samsung/ER-2710 and ER-2715 service manual](https://the-checkout-tech.com/manuals/samsung/ER-2710%20and%20ER-2715%20service%20manual)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)