

ELECTRONIC CASH REGISTER ER-290

SERVICE Manual

ELECTRONIC CASH REGISTER



CONTENTS

- 1. Precautions
- 2. Product Specifications
- Operating Instructions and Installation
- 4. Disassembly and Reassembly
- 5. Alignment and Adjustments
- 6. Troubleshooting
- 7. Exploded View and Parts List
- 8. Electrical Parts List
- 9. Block Diagram
- 10. PCB Diagrams
- 11. Wiring Diagram
- 12. Schematic Diagram

About this Manual

This service manual describes how to perform hardware service maintenance for the Samsung ER-290 Electronic Cash Register.

Acronym	Definition
ECR	Electronic Cash Register
ESD	Electro-statically Sensitive
	Device
GND	Ground
IC	Integrated Circuit
N.C.	Not Connected
PBA	Printed Board Assembly
PCB	Printed Circuit Board
RAM	Random Access Memory
ROM	Read Only Memory
SRAM	Static Random Access
	Memory

Notes

Note: Notes may appear anywhere in the manual. They draw your attention to additional information about the item.

Precaution symbols

 \triangle . indicates a Safety Precaution applies to this part component.

△. indicates the part or component is an electro-statically sensitive device. Use caution when handling these parts.

Copyright

 (\bar{c}) 1997 by Samsung Electronics Co., Ltd.

All right reserved.

This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, or converted to any electronic or machine readable from without prior written permission of Samsung Electronics Co., Ltd. ER-290 Service Manual First edition.

May 1997.

Printed in Korea

Contents List

1. Precaution Statements

- 1-1 Safety Precautions
- 1-2 Servicing Precautions
- 1-3 Precautions for Electrostatically Sensitive Devices (EDSs)

2. Product Specifications

- 2-1 Specifications
- 2-2 Dimensions

3. Installation and Operation

- 3-1 Key Board Installation
- 3-2 Handling the Printer
- 3-2-1 Precautions on the Printer Handling
- 3-2-2 Paper Setting
- 3-2-3 Installation / Removal of the Ribbon
- 3-3 Operation
- 3-3-1 ECR Feature
- 3-3-2 Mode Switch
- 3-3-3 Key Board Matrix

4. Disassembly and Reassembly

4-1 Disassembling

- 4-1-1 Upper Case Disassembly
- 4-1-2 Model-405R (Epson) Printer Disassembly
- 4-1-3 Main Board Disassembly
- 4-1-4 Display Board Disassembly
- 4-1-5 Mode Key Disassembly
- 4-1-6 Lower Case Disassembly

4-2 Reassembling

Samsung ER-290

5. Alignment and Adjustments

- 5-1 Position of the Timing Detector Assembly
- 5-2 Position of the Ribbon Shift Magnet Assembly
- 5-3 Printer Terminal Arrangement
- 5-4 Detailed Specifications
- 5-4-1 Character Arrangement
- 5-4-2 Paper
- 5-4-3 Ink Ribbon

6. Troubleshooting and Test Procedures

- 6-1 Troubleshooting
- 6-2 Test Procedures
- 6-2-1 All Clear
- 6-2-2 Test

7. Exploded View and Parts List

- 7-1 Exploded View
- 7-2 Exploded Parts List
- 7-3 Window Display
- 7-4 Turret PCB Assembly
- 7-5 Mode Switch Assembly
- 7-6 Key Board Assembly Exploded View
- 7-7 Key Board Assembly
- 7-8 Printer Assembly Exploded View
- 7-9 Printer Assembly
- 7-10 Drawer Assembly Exploded View
- 7-11 Drawer Assembly
- 7-11-1 Assembly Cover
- 7-11-2 Assembly Tray
- 7-11-3 Assembly Lock

Contents List Samsung ER-290

8. Electrical Parts List 8-1 Main PCB 8-2 Main Auto 9. Block Diagram 9-1 Main 9-2 Front / Rear Display Driver 9-3 Printer Driver 9-4 Key Board 9-5 CPU Port Description 10. PCB Diagrams 10-1 Main PCB 10-2 Window Display PCB 10-3 Turret (Rear Display) PCB 11. Wiring Diagrams 11-1 Main PCB 11-2 Window Display PCB 11-3 Turret (Rear Display) PCB 12. Schematic Diagrams 12-1 Power Part 12-2 Main Part 12-2-1 Window Display Part (Window PCB) 12-3 Printer Terminal Pin Assignments 12-3-1 CN5 12-3-2 CN6 12-4 Printer Timing Chart 12-4-1 1 Line Printing 12-4-2 Continuous Printing

12-4-3 Timing Chart

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/samsung/ER-290 service manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM