


# SAM4S

**ELECTRONIC CASH REGISTER  
ER-430 SERIES**

# ***SERVICE* Manual**

**ELECTRONIC CASH REGISTER**



**C O N T E N T S**

1. Precaution Statements
2. Product Specifications
3. Installation and Operation
4. Disassembly and Assembly
5. Maintenance and Adjustment
6. Exploded Views and Parts List
7. PCB Layout and Parts List
8. Troubleshooting
9. Block diagram
10. Wiring Diagram
11. Schematic Diagrams

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/samsung/ER-430 series service manual.html](https://the-checkout-tech.com/manuals/samsung/ER-430%20series%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)