

SAM4S

SAM4s ER-5115 Electronic Cash Register

Operator's and Programming Manual



All specifications are subject to change without notice.

©2005, CRS, Inc.
M-ER5115 Version 2.0

CRS, Inc.

Limited Warranty and Disclaimers of Warranty

This manual has been developed by CRS, Inc. It is intended for the use of its customers and service personnel and should be read in its entirety before attempting to install, use or program the product(s).

Nothing contained in this manual shall be deemed to be, and this manual does not constitute, a warranty of, or representation with respect to, the product or any of the products to which this manual applies. This manual is subject to change without notice and CRS, Inc. has no obligation to provide any updates or corrections to this manual. Further, CRS, Inc. also reserves the right, without prior notice, to make changes in equipment design or components as it deems appropriate. No representation is made that this manual is complete or accurate in all respects and CRS, Inc. shall not be liable for any errors or omissions contained in this manual. In no event shall CRS, Inc. be liable for any incidental or consequential damages relating to or arising out of the use of this manual. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied or reproduced without prior written consent of CRS, Inc.

NOTICE

IF ANY WARRANTY IS EXTENDED TO YOU WITH REGARD TO THE PRODUCT(S) TO WHICH THIS MANUAL APPLIES, IT IS A WARRANTY FROM THE ENTITY OR INDIVIDUAL FROM WHOM YOU DIRECTLY PURCHASED THE PRODUCT(S).

SUBJECT TO THE FOREGOING, UNLESS YOU ARE A DIRECT END USER CUSTOMER OF CRS, INC., CRS, INC. DOES NOT EXTEND TO YOU ANY EXPRESS WARRANTY OR ANY IMPLIED WARRANTY AND EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR USE, OR FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OF NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS IN CONNECTION WITH THE PRODUCT(S) OR ANY SOFTWARE, DRIVERS, OR PROGRAMMING PRODUCT, WHETHER EMBEDDED IN PRODUCT(S) OR PROVIDED AS A SEPARATE PROGRAM, OR USED IN CONJUNCTION WITH THIS/THESE PRODUCT(S). CRS, INC. SPECIFICALLY DOES NOT WARRANT THAT THE OPERATION OF ANY DRIVERS, SOFTWARE, OR PROGRAMMING PRODUCTS LICENSED HEREUNDER, WHETHER EMBEDDED IN PRODUCTS OR PROVIDED AS SEPARATE PROGRAMS, SHALL BE UNINTERRUPTED OR ERROR FREE OR THAT FUNCTIONS CONTAINED IN SUCH DRIVERS, SOFTWARE OR PROGRAMMING PRODUCTS SHALL OPERATE IN COMBINATION(S) WHICH MAY BE SELECTED FOR USE BY YOU OR OTHERWISE MEET YOUR REQUIREMENTS.

CRS, Inc. is not responsible for any damages or loss, either direct, indirect, special, incidental or consequential, which you may experience as a result of your purchase or use of the product(s). Your sole remedy in the event that you encounter any difficulties with the product(s) is against the entity or individual from whom you purchased the product(s).

Revision 2.0 - April 1, 2005

WARNING - U.S.

THIS EQUIPMENT GENERATES, USES AND CAN RADIATE RADIO FREQUENCY ENERGY, AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS MANUAL, MAY CAUSE INTERFERENCE TO RADIO COMMUNICATIONS. IT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A COMPUTING DEVICE PURSUANT TO SUBPART J OF PART 15 OF FCC RULES WHICH ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST SUCH INTERFERENCE WHEN OPERATED IN A COMMERCIAL ENVIRONMENT. OPERATIONS OF THE EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE INTERFERENCE IN WHICH CASE THE USER, AT HIS OWN EXPENSE, WILL BE REQUIRED TO TAKE WHATEVER MEASURES MAY BE REQUIRED TO CORRECT THE INTERFERENCE.

NOTICE - CANADA

THIS APPARATUS COMPLIES WITH THE CLASS "A" LIMITS FOR RADIO INTERFERENCE AS SPECIFIED IN THE CANADIAN DEPARTMENT OF COMMUNICATIONS RADIO INTERFERENCE REGULATIONS.

CET APPAREIL EST CONFORME AUX NORMES CLASS "A" D'INTERFERENCE RADIO TEL QUE SPECIFIER PAR MINISTRE CANADIEN DES COMMUNICATIONS DANS LES REGLEMENTS D'INTERFERENCE RADIO.

ATTENTION

The product that you have purchased may contain a battery that may be recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of the battery into the municipal waste system.



Check with your local solid waste officials for details concerning recycling options or proper disposal.

Precaution Statements

Follow these safety, servicing and ESD precautions to prevent damage and to protect against potential hazards such as electrical shock.

1-1 Safety Precautions

1. Be sure that all built-in protective devices are replaced. Restore any missing protective shields.
2. When reinstalling the chassis and its assemblies, be sure to restore all protective devices, including nonmetallic control knobs and compartment covers.
3. Make sure there are no cabinet openings through which people - particularly children - might insert fingers and contact dangerous voltages. Such openings include excessively wide cabinet ventilation slots and improperly fitted covers and drawers.
4. Design Alteration Warning:
Never alter or add to the mechanical or electrical design of the SECR. Unauthorized alterations might create a safety hazard. Also, any design changes or additions will void the manufacturer's warranty.
5. Components, parts and wiring that appear to have overheated or that are otherwise damaged should be replaced with parts that meet the original specifications. Always determine the cause of damage or over- heating, and correct any potential hazards.
6. Observe the original lead dress, especially near the following areas: sharp edges, and especially the AC and high voltage supplies. Always inspect for pinched, out-of-place, or frayed wiring. Do not change the spacing between components and the printed circuit board. Check the AC power cord for damage. Make sure that leads and components do not touch thermally hot parts.
7. Product Safety Notice:
Some electrical and mechanical parts have special safety-related characteristics that might not be obvious from visual inspection. These safety features and the protection they give might be lost if the replacement component differs from the original - even if the replacement is rated for higher voltage, wattage, etc.

Components that are critical for safety are indicated in the circuit diagram by shading, () or (). Use replacement components that have the same ratings, especially for flame resistance and dielectric strength specifications. A replacement part that does not have the same safety characteristics as the original might create shock, fire or other hazards.

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

Dispose used batteries according to the manufacturer's instructions.

ATTENTION

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie.

Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

1-2 Servicing Precautions

WARNING: First read the-Safety Precautions-section of this manual. If some unforeseen circumstance creates a conflict between the servicing and safety precautions, always follow the safety precautions.

WARNING: An electrolytic capacitor installed with the wrong polarity might explode.

1. Servicing precautions are printed on the cabinet. Follow them.
2. Always unplug the units AC power cord from the AC power source before attempting to:
 - (a) Remove or reinstall any component or assembly
 - (b) Disconnect an electrical plug or connector
 - (c) Connect a test component in parallel with an electrolytic capacitor
3. Some components are raised above the printed circuit board for safety. An insulation tube or tape is sometimes used. The internal wiring is sometimes clamped to prevent contact with thermally hot components. Reinstall all such elements to their original position.
4. After servicing, always check that the screws, components and wiring have been correctly reinstalled. Make sure that the portion around the serviced part has not been damaged.
5. Check the insulation between the blades of the AC plug and accessible conductive parts (examples : metal panels and input terminals).
6. Insulation Checking Procedure:

Disconnect the power cord from the AC source and turn the power switch ON. Connect an insulation resistance meter (500V) to the blades of AC plug.

The insulation resistance between each blade of the AC plug and accessible conductive parts (see above) should be greater than 1 megohm.
7. Never defeat any of the B+ voltage interlocks. Do not apply AC power to the unit (or any of its assemblies) unless all solid-state heat sinks are correctly installed.
8. Always connect an instrument's ground lead to the instrument chassis ground before connecting the positive lead ; always remove the instrument's ground lead last.

1-3 Precautions for Electrostatically Sensitive Devices (ESDs)

1. Some semiconductor (solid state) devices are easily damaged by static electricity. Such components are called Electrostatically Sensitive Devices (ESDs); examples include: integrated circuits and some field-effect transistors. The following techniques will reduce the occurrence of component damage caused by static electricity.
2. Immediately before handling any semiconductor components or assemblies, drain the electrostatic charge from your body by touching a known earth ground. Alternatively, wear a discharging wrist-strap device. (Be sure to remove it prior to applying power - this is an electric shock precaution.)
3. After removing an ESD-equipped assembly, place it on a conductive surface such as aluminum foil to prevent accumulation of electrostatic charge.
4. Do not use freon-propelled chemicals. These can generate electrical charges that damage ESDs.
5. Use only a grounded-tip soldering iron when soldering or unsoldering ESDs.
6. Use only an anti-static solder removal device. Many solder removal devices are not rated as anti-static; these can accumulate sufficient electrical charge to damage ESDs.
7. Do not remove a replacement ESD from its protective package until you are ready to install it. Most replacement ESDs are packaged with leads that are electrically shorted together by conductive foam, aluminum foil or other conductive materials.
8. Immediately before removing the protective material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.
9. Minimize body motions when handling unpackaged replacement ESDs. Motions such as brushing clothes together, or lifting a foot from a carpeted floor can generate enough static electricity to damage an ESD.

Contents

Introduction	7
About the <i>SAM4s ER-5115</i>	7
Using This Manual	8
Using Flowcharts	8
Basic Features and Functions	9
Display	10
Printer	14
Sample Receipt	14
Changing the Printer Ribbon Cartridge	16
Changing Paper	17
Control Lock	19
Keyboard	20
Operations	21
Overview	21
Function Key Descriptions	21
Clerk Sign-On/Sign-Off	25
Direct Sign-On	25
Coded Sign-On	25
Receipt On and Off	26
PLU Registrations	27
Keyboard PLU Entries	27
Keyboard PLU Level Entries	30
Numeric PLU Entries	31
Percentage Key (%) Registrations	33
Void and Correction Operations	36
Error Correct	36
Previous Item Void	37
Merchandise Return	38
VOID Control Lock Position (Transaction Void)	39
Cancel	40
Subtotal Operations	41
Subtotal	41
Tray Subtotal (Add Check)	41
Eat-In/Take-Out/Drive Thru Operations	42
Tax Shift Operations	43
Tendering Operations	45
Cash	45
Check	45
Charge	46
Split Tender	47
Post Tendering	47
Receipt on Request	48

Validation.....	48
Training Mode.....	49
Non-Add Number.....	50
No Sale.....	50
Received on Account.....	51
Paid Out.....	52
Restaurant Operations	53
Posting Guest Checks with the Previous Balance Key.....	53
Tracking Balances with the TABLE # Key.....	54
Payments	55
Optional Check Printer Sample Printout	56
Promo Function.....	57
Waste Function	57
Currency Conversion.....	58
Food Stamp Operations.....	59
Scale Operations.....	60
Direct Scale Entry	60
Manual Weight Entry.....	60
Scale With Automatic Tare Entry	61
Scale With Manual Tare Entry.....	61

Management Functions 63

Introduction.....	63
Manager Authorization Of Restricted Operations	63
Changing the Default PLU Level	64
Cash Declaration	64
System Reports.....	66
Running a Report - General Instructions.....	66
Report Table	67
Financial Report Example (Report #1)	68
Time Report Example (Report #2).....	73
All PLU Report Example (Report #3).....	74
All Clerk Report Example (Report #4)	76
Cash-In-Drawer Report Example (Report #5).....	80
Check-In-Drawer Report Example (Report #6)	80
Food Stamp-In-Drawer Report Example (Report #7)	80
Daily Sales Report Example (Report #8)	81
Item by Group Report Example (Report #10).....	82
Open Table Report Example (Report #11)	84
Inventory PLU Report Example (Report #12)	85
Group Report Example (Report #20).....	86
System Balancing	87
PLU Sales Total	87
Net Sales	87
Gross Sales.....	87
Grand Total.....	88

Programming 89

Overview	89
Default Program.....	90
Function Key Assignment Programming.....	91
Function Key Codes.....	92
Tax Programming.....	93

Straight Percentage Tax Rate Programming	94
Tax Table Programming	95
PLU Programming	97
Program 100 - PLU Status Programming.....	99
Program 150 - PLU Group Assignment	101
Program 200 - PLU Price/HALO Programming	102
Program 250 - PLU Stock Amount Programming	103
Program 300 - PLU Descriptor Programming	104
Program 400 - PLU Link Programming.....	106
System Option Programming	108
System Option Table.....	109
Function Key Programming	114
Program 70 - Function Key Options	116
Program 80 - Function Key Descriptor	117
Program 90 - Function Key HALO.....	118
#/No Sale - Function Key Programs	119
Cancel - Function Key Programs	120
Cash - Function Key Programs	121
Charge - Function Key Programs	122
Check - Function Key Programs	123
Check Cashing - Function Key Programs	124
Currency Conversion - Function Key Programs	125
Drive Thru - Function Key Programs.....	126
Eat-In - Function Key Programs	127
Error Correct - Function Key Programs	128
Food Stamp Tender - Function Key Programs.....	129
Guest # - Function Key Programs	130
Previous Balance - Function Key Programs.....	131
Promo - Function Key Programs.....	132
Paid Out - Function Key Programs	133
Received on Account - Function Key Programs	134
Return - Function Key Programs.....	135
Scale - Function Key Programs.....	136
Service - Function Key Programs	136
Table # - Function Key Programs	137
Take Out - Function Key Programs	138
Tax Exempt - Function Key Programs.....	139
Tray Subtotal - Function Key Programs.....	140
Void - Function Key Programs	141
Waste - Function Key Programs	142
% Key - Function Key Programs	143
Clerk Programming	145
Program 800 - Secret Code Programming	146
Program 801 - Drawer Assignment	146
Program 810 - Clerk Descriptor Programming	147
Miscellaneous Programming	149
Program 95 - Macro Key Sequence Programming.....	149
Receipt/Check Endorsement Message Programming.....	150
Group Status and Descriptor Programming	152
Scale Tare Weight Programming.....	154
Drawer Limit Programming	155
Machine Number Programming.....	155
Default Level Programming	156
Date and Time Programming	157
PC Schedule Operation Programming	158

Program Scans.....	159
PLU Program Scan.....	160
Tax Program Scan.....	161
Function Key Program Scan.....	162
Clerk Program Scan	163
Group Descriptor Program Scan	164
Receipt Message Program Scan	165
System Option/Default level/ Drawer Limit/Tare Scan.....	166
Key Location Program Scan	167
Macro Program Scan.....	168
Glossary of Terms	169
Index	173

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/samsung/ER-5115 operating programming manu](https://the-checkout-tech.com/manuals/samsung/ER-5115%20operating%20programming%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)