



*ER-650/650R*

# Operation and Program Manual



All specifications are subject to change without notice

**ATTENTION**

The product that you have purchased contains a rechargeable Ni-MH battery. This battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of the battery into the municipal waste system.

Check with your local solid waste officials for details concerning recycling options or proper disposal.

**WARNING**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## Precaution Statements

Follow these safety, servicing and ESD precautions to prevent damage and to protect against potential hazards such as electrical shock.

### 1-1 Safety Precautions

1. Be sure that all built-in protective devices are replaced. Restore any missing protective shields.
2. When reinstalling the chassis and its assemblies, be sure to restore all protective devices, including nonmetallic control knobs and compartment covers.
3. Make sure there are no cabinet openings through which people - particularly children - might insert fingers and contact dangerous voltages. Such openings include excessively wide cabinet ventilation slots and improperly fitted covers and drawers.
4. Design Alteration Warning:  
Never alter or add to the mechanical or electrical design of the SECR. Unauthorized alterations might create a safety hazard. Also, any design changes or additions will void the manufacturer's warranty.
5. Components, parts and wiring that appear to have overheated or that are otherwise damaged should be replaced with parts that meet the original specifications. Always determine the cause of damage or over-heating, and correct any potential hazards.
6. Observe the original lead dress, especially near the following areas : sharp edges, and especially the AC and high voltage supplies. Always inspect for pinched, out-of-place, or frayed wiring. Do not change the spacing between components and the printed circuit board. Check the AC power cord for damage. Make sure that leads and components do not touch thermally hot parts.
7. Product Safety Notice:  
Some electrical and mechanical parts have special safety-related characteristics which might not be obvious from visual inspection. These safety features and the protection they give might be lost if the replacement component differs from the original - even if the replacement is rated for higher voltage, wattage, etc.  
Components that are critical for safety are indicated in the circuit diagram by shading, () or (). Use replacement components that have the same ratings, especially for flame resistance and dielectric strength specifications. A replacement part that does not have the same safety characteristics as the original might create shock, fire or other hazards.

#### CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

Dispose used batteries according to the manufacturer's instructions.

#### ATTENTION

Il y a danger d'explosion s'il y a un remplacement incorrect de la batterie.

Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.



## 1-2 Servicing Precautions

**WARNING:** First read the-Safety Precautions-section of this manual. If some unforeseen circumstance creates a conflict between the servicing and safety precautions, always follow the safety precautions.

**WARNING:** An electrolytic capacitor installed with the wrong polarity might explode.

1. Servicing precautions are printed on the cabinet. Follow them.
2. Always unplug the units AC power cord from the AC power source before attempting to:
  - (a) Remove or reinstall any component or assembly
  - (b) Disconnect an electrical plug or connector
  - (c) Connect a test component in parallel with an electrolytic capacitor
3. Some components are raised above the printed circuit board for safety. An insulation tube or tape is sometimes used. The internal wiring is sometimes clamped to prevent contact with thermally hot components. Reinstall all such elements to their original position.
4. After servicing, always check that the screws, components and wiring have been correctly reinstalled. Make sure that the portion around the serviced part has not been damaged.
5. Check the insulation between the blades of the AC plug and accessible conductive parts (examples : metal panels and input terminals).
6. Insulation Checking Procedure:

Disconnect the power cord from the AC source and turn the power switch ON. Connect an insulation resistance meter (500V) to the blades of AC plug.

The insulation resistance between each blade of the AC plug and accessible conductive parts (see above) should be greater than 1 megohm.
7. Never defeat any of the B+ voltage interlocks. Do not apply AC power to the unit (or any of its assemblies) unless all solid-state heat sinks are correctly installed.
8. Always connect an instrument's ground lead to the instrument chassis ground before connecting the positive lead ; always remove the instrument's ground lead last.

## 1-3 Precautions for Electrostatically Sensitive Devices (ESDs)

1. Some semiconductor (solid state) devices are easily damaged by static electricity. Such components are called Electrostatically Sensitive Devices (ESDs); examples include integrated circuits and some field-effect transistors. The following techniques will reduce the occurrence of component damage caused by static electricity.
2. Immediately before handling any semiconductor components or assemblies, drain the electrostatic charge from your body by touching a known earth ground. Alternatively, wear a discharging wrist-strap device. (Be sure to remove it prior to applying power - this is an electric shock precaution.)
3. After removing an ESD-equipped assembly, place it on a conductive surface such as aluminum foil to prevent accumulation of electrostatic charge.
4. Do not use freon-propelled chemicals. These can generate electrical charges that damage ESDs.
5. Use only a grounded-tip soldering iron when soldering or unsoldering ESDs.
6. Use only an anti-static solder removal device. Many solder removal devices are not rated as anti-static; these can accumulate sufficient electrical charge to damage ESDs.
7. Do not remove a replacement ESD from its protective package until you are ready to install it. Most replacement ESDs are packaged with leads that are electrically shorted together by conductive foam, aluminum foil or other conductive materials.
8. Immediately before removing the protective material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.
9. Minimize body motions when handling unpackaged replacement ESDs. Motions such as brushing clothes together, or lifting a foot from a carpeted floor can generate enough static electricity to damage an ESD.



# Contents

<b>Getting Started</b>	<b>1</b>
About the <i>ER-650/650R</i> .....	1
Using this Manual.....	2
Unpacking.....	2
Installing the Paper.....	3
Basic Features and Functions.....	6
Standard Hardware.....	6
Optional Hardware.....	6
Software Features.....	6
ER-650 Default Keyboard.....	8
ER-650 Program Overlay.....	8
ER-650R Default Keyboard.....	9
ER-650R Program Overlay.....	9
Programmable Function Keys.....	10
Control Lock.....	14
Front Display.....	15
Rear Display.....	18
Initial Clear.....	19
<b>Operating Instructions</b>	<b>21</b>
Operator Display Screen.....	21
Operator Display Example.....	22
Clerk Operations.....	23
Clerk Sign On Instructions.....	24
Clerk Sign Off Instructions.....	24
Clerk Time Keeping.....	25
Item Registrations.....	27
Open Keyboard PLU Entry.....	28
Preset Price Keyboard PLU.....	28
Keyboard PLU Repeat Entry.....	29
Keyboard PLU Multiplication.....	30
Keyboard PLU Multiplication with Decimal Point.....	31
Split Pricing (Keyboard PLU).....	32
Single Item Keyboard PLU.....	33
Open Code Entry PLU.....	34
Preset Price Code Entry PLU.....	34
Code Entry PLU Multiplication.....	35
Code Entry PLU Multiplication with Decimal Point.....	36
Split Pricing Code Entry PLU.....	36
PLU Price Inquiry.....	37
Modifier Key.....	38
Price Level Key.....	39
Promo.....	40

Waste .....	41
Shifting or Exempting Tax .....	42
Shifting Tax .....	42
Exempting Tax .....	43
Percent Key Operations .....	45
Preset Percent Discount on an Item .....	45
Enter a Percent Discount on an Item .....	46
Percent on Sale Total .....	46
Coupon on Sale (Vendor Coupon) .....	47
Coupon on Item (Store Coupon) .....	48
Return Merchandise Registrations .....	49
Voids and Corrections .....	50
Error Correction (Void Last Item) .....	50
Void Previous Item .....	50
Cancel .....	51
Void Position Operations .....	51
No Sale Operations .....	52
Open Drawer .....	52
Non Add Number .....	52
Received On Account Operations .....	53
Paid Out Operations .....	54
Subtotaling a Sale .....	55
Eat In/Take Out/Drive Thru Sales .....	55
Totaling and Tendering .....	56
Totaling a Cash Sale .....	56
Totaling a Check Sale .....	56
Tendering a Cash Sale .....	57
Tendering a Check Sale .....	57
Totaling a Charge Sale .....	58
Tendering a Charge Sale .....	59
Check Cashing .....	60
Split Tender .....	61
Post Tender .....	62
Food Stamp Sales .....	63
Currency Conversion .....	64
Receipt On/Off and Receipt on Request .....	65
Check Tracking Operations .....	66
Overview .....	66
Posting Balances Manually .....	68
Soft Check .....	70
Hard Check .....	73
Fast Food Drive Thru .....	76
Scale Operations .....	78
Direct Scale Entry .....	79
Automatic Scale Entry .....	80
Tare Weight Entry .....	80
Manual Tare Weight Entry .....	81
Manual Weight Entry .....	82

## X Mode

**83**

Manager Mode .....	83
Manager Operation .....	84
X Reports .....	85
Declaration .....	87

Register Print Format.....	88
Stop Register Printing.....	89
Training Mode.....	90
E.J. Operation.....	91

## **Z Mode 93**

Reset Report Mode.....	93
Z Reports.....	94
Reset Electronic Journal.....	96
PC Communication.....	96
PLU Lookup Program.....	97
Age Verification.....	99
KP Starting No.....	100

## **Service Mode Programming 101**

Overview.....	101
Clearing Memory.....	103
Memory All Clear.....	103
Hardware Test.....	105
Hardware Test Table.....	105
Clear All Totals.....	106
Clear Grand Total.....	106
Clear PLU File.....	107
EPROM Information.....	107
Memory Allocation.....	108
Function Key Assignment.....	110
Function Key Codes.....	112
IRC Options.....	113
RS232C Port 1/RS232C Port 2 Options.....	114
RS232C Settings Screen Program Notes.....	117

## **Program Mode Programming 119**

Descriptor Programming Methods.....	119
Program Overlay Method.....	119
Descriptor Code Method.....	120
Program Mode Menu.....	121
PLU Programming.....	123
Add/Modify PLU.....	123
PLU Options - Reference Information.....	126
Delete PLU.....	128
Group Programming.....	131
Sales Tax Programming.....	134
Programming an Add-On Tax Rate Percentage.....	135
Programming a Tax Table.....	136
Programming a VAT (Value Added Tax).....	140
Programming a Canadian GST.....	141
System Option Programming.....	142
System Options - Reference Information.....	146
Print Option Programming.....	150
Clerk Programming.....	158
Clerk Programming - Reference Information.....	159
Function Key Programming.....	160
#/NS.....	161

% 1 -%5 .....	163
ADD CHECK.....	166
CANCEL.....	168
CASH.....	169
CHARGE 1-8.....	171
CHECK CASHING.....	173
CHECK ENDORSEMENT.....	174
CHECK.....	176
CHECK #.....	178
CURRENCY CONVERSION 1-4.....	180
EAT-IN TAKE OUT DRIVE THRU.....	181
ERROR CORRECT.....	182
F/S TEND.....	183
FUNCTION LOOK UP (1-2).....	185
GUEST.....	187
LEVEL 1-5.....	188
MDSE RETURN.....	189
MODIFIER 1-5.....	190
PBAL.....	192
PAID OUT 1-3.....	193
PRINT CHECK.....	194
PROMO.....	195
RECD ON ACCT 1-3.....	196
SCALE.....	197
SERVICE.....	199
TABLE.....	201
TARE.....	202
TAX EXEMPT.....	203
TIME IN/OUT.....	204
TIP.....	205
VALIDATE.....	207
VOID ITEM.....	208
WASTE.....	209
Logo Descriptor.....	210
Preamble.....	211
Postamble.....	212
Endorsement Message.....	213
Financial Report.....	214
Clerk Report.....	215
Macro Name.....	216
NLU Code Number.....	217
Download Programs.....	218
Clerk In/Out.....	220
PLU Stock.....	221
Drawer Limit.....	222
Check Change Limit.....	223
Time & Date.....	224
Tare Weight.....	225
Macro.....	226
Programming a New Macro.....	227
Editing an Existing Macro.....	228
Machine No. ....	229
PC Schedule Time.....	230
Training Mode Password.....	231
Program Scans.....	232

<b>Sample Reports</b>	<b>235</b>
Financial .....	235
Time .....	239
PLU.....	240
Clerk .....	241
Individual Clerk .....	242
Groups .....	243
Stock .....	244
Clerk Time Report .....	245
Check File.....	246
PLU Zero Sale .....	247
Balancing Formulas .....	248
 <b>Glossary of Terms</b>	 <b>249</b>
 <b>Index</b>	 <b>255</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/samsung/ER-650 and ER-650R operating program.pdf](https://the-checkout-tech.com/manuals/samsung/ER-650%20and%20ER-650R%20operating%20program.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)